LE71001753

Sprecher and Schuh L7 Switch Body 3 Pole Off On Panel Mount 100A



Component type	Off-load switch
Range	L7 Loadbreak Switch
Model	N/A
Product status	Existing

The Sprecher + Schuh L7 line is compact, reliable and the ideal choice for all disconnect applications. All accessories snap-on and off for quick assembly. The L7's modular design allows for multiple combinations and use of universal accessories. Available in base (LA7) and panel (LE7) mount options up to 100A with easy selection, needing only two part numbers to build a complete switch assembly.

ELECTRICAL	Number of poles	3
	Rated operation power at AC-3, 400 V	37 kW
	Rated operation current Ie at AC-21a, 690V	100 A
	Rated operation current Ie at AC-1, 690V	100 A
	Ithe, thermal current (enclosed)	100 A
	Ith, thermal current (open)	120 A
	Number of auxiliary contacts as normally closed contact	0
	Number of auxiliary contacts as normally open contact	0
CONSTRUCTION	Model	On/Off switch
	Mounting method	Front mounting
	Material housing	Plastic
	Wire/conductor size, rigid cable	4-35 mm²
	Wire/conductor size, flex cable	4-50 mm²
	Degree of protection (IP), front side	IP20
	Suitable for front mounting	Yes
	Complete device in housing	No
MECHANICAL	With zero (off) position	Yes
	Mechanical life (service cycles)	200000 cycles
	Number of switch positions	2
DIMENSIONS	Depth	90 mm
	Width	72 mm
	Height	90 mm
ENVIRONMENT	Operating temperature	-25…60 °C


Published on 29 October 2026

LE71001753

Sprecher and Schuh L7 Switch Body 3 Pole Off On Panel Mount 100A

DIMENSIONAL DIAGRAM

LE 7 - panel mounted switches - 3 pole (16 ... 100 A)



Type	B1	B2	F	H	L
LE 7-16	-	-	36	63	51
LE 7-25/32	-	36	45	64	60
LE 7-40/63	48	36	54	72	74
LE 7-80/100	48	36	72	90	90

Control handles

Cat. No.	Q	P	B
LFS 2-A-4	48 x 48	28	36
LFS 2-E-4	48 x 48	28	48
LFS 2-A-6	64 x 64	28	48
LFS 2-E-6	64 x 64	28	48
LFS 7-N-4-175	54 X 54	28	28
LFS 2-N-6	67 x 67	34	48
LFS 2-G-6	67 x 67	34	48
LFS 7-G-4-175	54 X 54	28	28

RELATED PRODUCTS

ACCESSORY



Item No: L780C3
Required: No
Description: Sprecher and Schuh L7 Terminal Cover 3 Pole suits LE and LA780 and 100 (QTY 1)

Item No: L7G3662
Required: No
Description: Sprecher and Schuh L7 Mechanical Coupling 6 Pole for L780 and 100




Item No: L7G3687
Required: No
Description: Sprecher and Schuh L7 Shaft Metal 44mm for LA7 and LA2



Item No: L7G3707
Required: No
Description: Sprecher and Schuh L7 Shaft Metal 54mm for LA7 and LA2

Item No: LA2G2830
Required: No
Description: Sprecher and Schuh L2 Cam Switch Shaft Extension Standard 44mm



Item No: LA2G2853
Required: No
Description: Sprecher and Schuh L2 Cam Switch Shaft Extension including Coupling 24mm

RELATED PRODUCTS

ACCESSORY

Item No: LA2G3194
Required: No
Description: Sprecher and Schuh L2 Cam Switch Shaft Extension Standard 52mm

Item No: LA2G3195
Required: No
Description: Sprecher and Schuh L2 Cam Switch Shaft Extension Standard 57mm



Item No: LA2G3393
Required: No
Description: Sprecher and Schuh L2 Cam Switch Metal Shaft Short Yellow 235mm



Item No: LA2G3394
Required: No
Description: Sprecher and Schuh L2 Cam Switch Metal Shaft Long Yellow 350mm

Item No: LA2G3399
Required: No
Description: Sprecher and Schuh L2 Cam Switch Insert To Modify Metal Shaft to Switch Any Position White



Item No: LE7100NP
Required: No
Description: Sprecher and Schuh L7 Fourth Pole for LE7100



Item No: LE7100PE
Required: No
Description: Sprecher and Schuh L7 Earth Terminal for LE780 and LE100

Item No: LE7100TN
Required: No
Description: Sprecher and Schuh L7 Neutral Terminal for LE780 and LE7100



Item No: LE7P11
Required: No
Description: Sprecher and Schuh L7 Auxiliary Contact 1 N.O + 1 N.C for LE716 to LE7100



Item No: LE7PD10
Required: No
Description: Sprecher and Schuh L7 Auxiliary Contact 1 N.O E.B for LE725 to LE7100



Item No: LE7PL11
Required: No
Description: Sprecher and Schuh L7 Auxiliary Contact 1 N.O E.M +1 N.C L.B for LE716 to LE7100



Item No: LFS2A6175
Required: No
Description: Sprecher and Schuh L7 Handle Std Type A BK/Silver Screw Fixing Mount 67 x 67mm Engraved O I



Item No: LFS2A6175I
Required: No
Description: Sprecher and Schuh L7 Handle Std Type A BK/Silver Screw Fixing Mount 67 x 67mm Engraved OFF ON



Item No: LFS2A6375
Required: No
Description: Sprecher and Schuh L7 Handle Std Type A BK/Silver Screw Fixing Mount 67 x 67mm Engraved 1 0 2



Item No: LFS2E6175
Required: No
Description: Sprecher and Schuh L7 Handle Std Padlock Type E BK/Silver Screw Fixing Mount 67 x 67mm Engraved O I



Item No: LFS2G6175
Required: No
Description: Sprecher and Schuh L7 Handle Disc Padlock Type G BK/GY Screw Fixing Mount 67 x 67mm Engraved OFF ON

Item No: LFS2G8175
Required: No
Description: Sprecher and Schuh L7 Handle Disc Padlock Type G BK/GY Screw Fixing Mount 90 x 90mm Engraved OFF ON

LE71001753

Sprecher and Schuh L7 Switch Body 3 Pole Off On Panel Mount 100A

RELATED PRODUCTS

ACCESSORY



Item No: LFS2I8175I

Required: No

Description: Sprecher and Schuh L7 Handle Std Type I RD/YL Screw Fixing Mount 88 x 88mm Engraved OFF ON

Item No: LFS2L6175

Required: No

Description: Sprecher and Schuh L7 Handle Std Padlock Type L RD/YL Screw Fixing Mount 64 x 64mm Engraved O I



Item No: LFS2N6175

Required: No

Description: Sprecher and Schuh L7 Handle Disc Padlock Type G RD/YL Screw Fixing Mount 67 x 67mm Engraved OFF ON