

TemBreak^{PRO}

P Model Moulded Case Circuit Breaker

Basic Electronic Trip Unit from 160A up to 630A

USER MANUAL



Version
1.8.0

Using this manual

Safety Precautions

Authorised Personnel Only

The product or system described in this documentation must be installed, operated and maintained by qualified personnel only. NHP or Terasaki accept no responsibility for the consequences of the use of this equipment by unqualified personnel.

A qualified person is one with the necessary skills and knowledge of the construction and operation of the installation of electrical equipment and has been trained to identify and avoid risks.

Appropriate use of NHP / Terasaki products

NHP / Terasaki products are intended to be used only for the applications described in the catalogue and technical documentation, which is dedicated to them. If products and components from other manufacturers are used, they must be recommended or approved by NHP or Terasaki.

Appropriate use of NHP / Terasaki products during transport, storage, installation, assembly, commissioning, operation and maintenance is necessary to ensure safe operation and without any problems.

The permissible ambient conditions must be met. The information contained in the technical documentation must be observed.

Publication of responsibility

The contents of this document have been reviewed to ensure that the reliability of the information is correct at time of publication.

NHP or Terasaki are not responsible for printing or damage resulting from errors. NHP or Terasaki reserve the right to make corrections and changes needed in subsequent edition.

Warnings and notes

This documentation contains safety instructions that you must follow for your personal safety and to prevent damage to property.

Safety instructions, referring to your personal safety are reported in the literature by a safety alert symbol.

Safety warning symbols and the words below are classified according to the degree of risk.



WARNING: Indicates an imminently hazardous situation which, if it cannot be avoided, will result in death or serious injury.



WARNING: Indicates a potentially hazardous situation which, if it cannot be avoided, can result serious injury or death.



WARNING: Indicates a potentially hazardous situation which, if it cannot be avoided, may cause minor or moderate injury.



Notice: Indicates a warning of property damage and can also indicate important operating and especially useful information on the product, that it should pay particular attention to efficient and safe operation.

Summary of Changes

This section highlights the details of changes made since the previous issue of this document.

The versioning convention used to track changes in this document follows the structure **Vx.y.z** where:

- x:** Major revision, where extensive changes are made which is generally incompatible with the previous version. Such changes may include new products and/or features, or removal of information which is no longer relevant or applicable to the previous version
- y:** Minor revision, where changes made do not change the overall scope of the previous version, but may include additional information which complements or corrects the previous version, or provides additional clarity on an existing topic.
- z:** Patch version, where small changes are made to correct minor errors or adjust existing text, charts, figures and/or images, and which do not add or remove information from the previous version. Example changes may include spelling corrections, image re-sizing and adjustments, updated images, etc.

| Version | Publication date | Changes | By |
|---------|------------------|---|--------|
| V 1.0.0 | 19-Apr-2021 | Initial release | D.NAT |
| V 1.1.0 | 26-Apr-2021 | Product information corrections | D.NAT |
| V 1.2.0 | 29-Apr-2021 | Neutral Protection information correction | D.NAT |
| V 1.3.0 | 13-May-2021 | Clearance distance corrections | N.ALEX |
| V 1.4.0 | 24-May-2021 | Temperature corrections and fixed typo on Part Number Break Down | N.ALEX |
| V 1.5.0 | 28-May-2021 | Label Identification section added, Temperature Rating tables aligned headings with TD-001-EN, I ² t Curves updated in image quality, added references and links to, TD-001-EN, TD-002-EN, TD-003-EN, & Type2_TBpro_MotorStartTables-TD-001-EN | N.ALEX |
| V 1.5.1 | 10-May-2021 | Fixed typo on P250 Let-through scale | N.ALEX |
| V 1.6.0 | 20-August-2021 | Fixed typo on Part Number Break Down, Correction to P160 Information table data, added resistance watts loss, rewording in Clearance section links to Installation Manuals added | N.ALEX |
| V 1.7.0 | 20-Jan-2022 | Changed watts loss and temperature tables to match TD-001-EN | N.ALEX |
| V 1.8.0 | 10-Feb-2022 | Added LTD Equation | N.ALEX |

Table of Contents

| | | | |
|---|-----------|--|-----------|
| Using this manual | 2 | Alarms & Indication | 39 |
| Safety Precautions | 2 | System Alarms | 39 |
| Summary of Changes | 3 | Trip Alarm | 40 |
| Table of Contents | 4 | PTA (Pre-Trip Alarm) | 41 |
| Introduction | 5 | OAC and PTA cable | 41 |
| Who Should Use This Manual? | 5 | OCR Power Supply | 42 |
| Additional resources | 5 | Commissioning | 43 |
| Terminology and Abbreviations | 6 | LTD Adjustments (I_r , t_r) | 43 |
| Product Information | 7 | STD Adjustments (I_{sd} , t_{sd}) | 44 |
| Part Number Break Down | 8 | INST Protection Adjustments (I_i) | 45 |
| Available MCCBs in the TemBreak <i>PRO</i> range: | 9 | INST Protection Only Setting | 46 |
| Label Identification | 10 | LSIG 3P – GF Protection Adjustments (I_g) | 47 |
| P160_BE and P250_BE Information | 11 | LSIG 4P – NP and GF Protection Adjustments (I_N , I_g) | 48 |
| P400_BE Information | 12 | Troubleshooting | 49 |
| P630_BE Information | 13 | Annex A – Dimensions | 51 |
| Internal Accessories | 14 | P160 Dimensions | 51 |
| Auxiliary & Alarm Switches | 14 | P250 Dimensions | 52 |
| Auxiliary Contact | 14 | P400 Dimensions | 53 |
| Alarm Contact | 14 | P630 Dimensions | 54 |
| Shunt Trip | 15 | Annex B – Trip Curves | 55 |
| Under Voltage Trips | 15 | Annex C – I^2t Let-Through Curves | 56 |
| Plugs & Ports | 16 | P160_BE | 56 |
| Installation | 17 | P250_BE | 57 |
| Precautions | 17 | P400_BE | 58 |
| Mounting Angles | 17 | P630_BE | 59 |
| Direction of Power Supply | 17 | Annex D – Peak Let Through Curves | 60 |
| Clearances | 18 | P160_BE | 60 |
| Internal Accessory Mounting Locations | 20 | P250_BE | 61 |
| P160 internal accessories combination | 20 | P400_BE | 62 |
| P250 internal accessories combination | 21 | P630_BE | 63 |
| P400/630 internal accessories combination | 22 | Annex E – Watts Loss | 64 |
| Alarm, Shunt & UVT Installation | 23 | Impedance Watts Loss | 64 |
| Standard Alarm & Auxiliary installation | 23 | Resistance Watts Loss | 64 |
| Shunt & UVT installation | 24 | Annex F – Rated Temperature Tables | 65 |
| Protection Settings | 25 | | |
| Trip Curve | 25 | | |
| Long Time Delay (LTD) protection | 26 | | |
| Adjusting I_r (Current) | 27 | | |
| Adjusting t_r (Time Delay) | 28 | | |
| Thermal memory / Hot–Cold start mode | 29 | | |
| Short Time Delay Protection (STD) | 30 | | |
| Adjusting I_{sd} (Current) | 31 | | |
| Adjusting t_{sd} (Time Delay) | 32 | | |
| I_{sd} Time Delay Adjustment Settings (ms) | 32 | | |
| I^2t function for STD | 33 | | |
| Thermal Self Protection | 35 | | |
| Instantaneous Protection (INST) | 36 | | |
| Adjusting I_i (Current) | 36 | | |
| Ground/Earth Fault Protection (GF) | 37 | | |
| Neutral Protection (NP) | 38 | | |

Introduction

This user manual describes the TemBreak *PRO* Basic Electronic (**P_BE**) MCCB features and instructions for use, and provides information for commissioning and configuring.

Some additional features may require the use of additional products and accessories to achieve full utilization of that feature. Refer the respective User Manual in the TemBreak *PRO* series for additional information on the respective product.



Notice: Not all OCRs in the TemBreak *PRO* series are identical. This document specifically covers the P_BE OCRs only. Refer to the respective OCR User Manual (e.g. B_SE, P_SE, etc.) for information and instructions on other OCRs in the TemBreak *PRO* series.

Who Should Use This Manual?

This manual aims to provide users, electricians, panel builders and maintenance personnel, with the technical information required for commissioning and operation of the NHP / Terasaki TemBreak *PRO* P_BE MCCB.

Users of this document must have at minimum a basic understanding of electrical circuit protection topics including (but not limited to):

- Power distribution and reticulation
- Circuit protection devices
- Fault currents
- Arc faults
- Temperature rise and thermal derating of switchgear

Additional resources

The following resources contain additional information which should be read in conjunction with this document.

| Resource | Description |
|---|--|
| NHP/Terasaki TemBreak <i>PRO</i> P_BE Installation Instructions P160 3 BE-IN-001-EN P160 4 BE-IN-001-EN P250 3 BE-IN-001-EN P250 4 BE-IN-001-EN P400 3 BE-IN-001-EN P400 4 BE-IN-001-EN P630 3 BE-IN-001-EN P630 4 BE-IN-001-EN | Information on installing, mounting, and wiring the TemBreak <i>PRO</i> Basic Electronic MCCB. |
| Technical Data – Temperature and Watts Loss TBP-TD-001-EN | Temperature and Watts Loss tables for TemBreak <i>PRO</i> Moulded Case Circuit Breakers. |
| Technical Data – Cascading and Selectivity TBP-TD-002-EN | Cascading and Selectivity tables for TemBreak <i>PRO</i> Moulded Case Circuit Breakers with Din-T, Din-Safe, & MOD6 MCBs/RCBOs |
| Technical Data – Coordination TBP-TD-003-EN | Socomec Backup Tables with TemBreak <i>PRO</i> Moulded Case Circuit Breakers |
| Technical Data – Type 2 Coordination Type2_TBpro_MotorStartTables-TD-001-EN | Type 2 Coordination for Premium Efficiency Motor Starters with TemBreak <i>PRO</i> Moulded Case Circuit Breakers |



Introduction

Terminology and Abbreviations

| Abbreviation | Description | Abbreviation | Description |
|---------------------------|--|-------------------------|--|
| ACP | Auxiliary Communications port: Plug for Smart auxiliary / alarm contact block | MIP | Maintenance Interface Port: Plug for temporary connection to OCR testing, servicing, and maintenance tools |
| AL | Alarm: An auxiliary contact indicating trip status | N | Neutral |
| ASCII | American Standard Code for Information Interchange | NP | Neutral Protection |
| AX or AUX | Auxiliary: Auxiliary contact indicating open / closed | OAC | Optional Alarm Contact: Connection connector optional alarm output contact |
| BE | Basic Electronic Trip Unit (dial type, LSI and LSIG) | OCR | Over Current Relay |
| CCW | Connected Components Workbench software | P or PTA | Pre-trip Alarm |
| CIP ^{1 2} | ¹ Communication Interface Port: Plug for control power and data for use with the TPED remote display and TPCM communication module ² Common Industrial Protocol | PDU | Protocol Data Unit |
| CRC | Cyclic Redundancy Check – error-detecting code used at the end of each Modbus message | PELV | Protected Extra Low Voltage (earthed system) |
| dec | Decimal (base-10) numbering system | PTA | Pre-Trip Alarm: is a programmable output contact to advise when a trip may be imminent. |
| DINT | Signed Double Integer datatype (4 bytes or 32 bits in length) | RTU | Remote Terminal Unit |
| EIPM | TemBreak <i>PRO</i> Ethernet/IP Module | S or STD | Short Time Delay Protection |
| FF | Fixed Thermal and Fixed Magnetic | SE | Smart Energy Trip Unit |
| FM | Fixed Thermal and Adjustable Magnetic | SELV | Separated Extra Low Voltage |
| G or GF | Ground Fault Protection | SN | Solid Neutral |
| hex | Hexadecimal (base-16) numbering system | SSID | Service Set Identifier (name of the Wi-Fi wireless network) |
| I or INST | Instantaneous Protection | STR | String datatype |
| IEC | International Electrotechnical Commission | TCP | Transmission Control Protocol |
| IEEE | Institute of Electrical and Electronics Engineers | TF | Adjustable Thermal and Fixed Magnetic |
| I_g | Ground Fault Protection Current | THD | Total Harmonic Distortion |
| I_i | Instantaneous Protection Current | TM | Adjustable Thermal Magnetic |
| I_n | Rated Current | TPCM | TemCom <i>PRO</i> Communication Module |
| I_N | Neutral Protection Current | TPED | TemView <i>PRO</i> External Display |
| INT | Signed Integer datatype (2 bytes or 16 bits in length) | t_r | LTD Time delay |
| IP | International Protection (Ingress Protection) | t_{sd} | STD Time delay |
| I_r | LTD Protection Current | t_{tsp} | Thermal Self-Protection Time delay |
| I_{sd} | STD Protection Current | UDINT | Unsigned Integer (2 bytes or 16-bits in length) |
| I_{tsp} | Thermal Self-Protection Current | UINT | Unsigned Integer (2 bytes or 16 bits in length) |
| L or LTD | Long Time Delay Protection | ULINT | Unsigned Long Integer datatype (8 bytes or 64 bits in length) |
| LCD | Liquid Crystal Display (LCD) | URLs | Uniform Resource Locator (address of an Internet website) |
| LED | Light Emitting Diode | WORD | 2 bytes or 16-bits of data |
| LINT | Signed Long Integer datatype (8 bytes or 64 bits in length) | ZSI | Zone Selective Interlocking (zone selectivity) |
| LSI | Long Time, Short Time and Instantaneous Protection | θ | Thermal imaging value |
| LSIG | Long Time, Short Time, Instantaneous and Ground Fault Protection | θ_c | Cold start mode thermal imaging value |
| MCCB | Moulded Case Circuit Breaker | θ_H | Hot start mode thermal imaging value |
| microSD | Micro Secure Digital | θ_{trip} | Thermal imaging value tripping threshold |

Product Information

The TemBreak *PRO* P model Basic Electronic MCCB with trip unit type P_BE, in addition to protecting against overloads and short circuits, offers flexibility via provide fully adjustable LSI(G) (long time, short time, instantaneous, ground fault) protection settings via preset rotary switches as well as a host of other standard or optional features. This allows for improved selectivity combinations between MCCBs or other circuit breaker types.



Features

- LSI or LSIG
- Setting by rotary dial
- Over temperature alarm LED
- Signalling the OCR LED status (Ready)
- Signalling PTA overload pre-warning LED
- LED signalling overload alarm ($>I_r$)
- Possible adjustment of thresholds and time delays for LSIG 6)
- Possible adjustment of the protection of neutral pole on 4-pole versions (neutral pole positioned to the right)

Frame Sizes

- P160
- P250
- P400
- P630

Protection Functions

- Long Time Delay
- Short Time Delay
- Instantaneous
- Ground Fault (LSIG model)
- Neutral Protection (LSIG 4P model)

Additional Certificates



Product Information

Part Number Break Down



a) Model Type

| | |
|----|--|
| A | Basic applications (160...250 A) |
| P | Mid to advanced applications (160...630 A) |
| B | High current, high kA applications (160...1600 A) |
| ZS | Earth Leakage applications (125...250 A) |
| XS | Highest current applications (2000...3200 A) |

b) Ampere Frame

| |
|--------|
| 125 A |
| 160 A |
| 250 A |
| 400 A |
| 630 A |
| 800 A |
| 1000 A |
| 1250 A |
| 1600 A |
| 2000 A |
| 2500 A |
| 3200 A |

c) Short Circuit Break Capacity I_{cu} (kA)

| | |
|----|--------|
| R | 200 kA |
| L | 150 kA |
| P | 125 kA |
| S | 110 kA |
| G | 100 kA |
| HL | 85 kA |
| H | 70 kA |
| M | 65 kA |
| N | 50 kA |
| F | 36 kA |
| E | 25 kA |
| D | Switch |

d) Pole Pitch Size (mm) ¹⁾

| | |
|---|----|
| 1 | 25 |
| 2 | 30 |
| 3 | 35 |

e) No. of Poles

| | |
|---|---------------|
| 1 | ⁷⁾ |
| 2 | ⁸⁾ |
| 3 | |
| 4 | |

f) Trip Unit Rating (I_n)

I_n x A

g) Trip Unit Type

| | |
|----|--|
| TF | Adj Thermal Fix Magnetic ⁴⁾ |
| FF | Fix Thermal Fix Magnetic |
| TM | Adj Thermal Adj Magnetic |
| SX | Smart Ammeter ^{5) 6)} |
| BE | Basic Electronic ⁶⁾ |
| SE | Smart Energy ⁶⁾ |
| NN | Non-Auto Switch |

h) Trip Unit Option

| | |
|----|------------------------------|
| G | Ground Fault ²⁾ |
| N | Neutral ²⁾ |
| P | Pre-Trip Alarm ³⁾ |
| SN | Solid Neutral ⁹⁾ |



Notice: Not all combinations are possible. Confirm part number combination with NHP for availability.

- 160AF only
- For P_SE versions these features are standard and therefore are not added to the end of the part number.
- PTA is standard with P electronic models and therefore P is not added to the end of the part number.
- Only available in A & ZS models
- Only available in B models
- Not available in A and ZS models
- Only available in A and B models (FF Only Trip Unit)
- Not available in A and B models (FF Only Trip Unit)
- ZS Models

Product Information


Available MCCBs in the TemBreak PRO range:




| Rating Short Circuit Break Capacity (kA) | | Frame Size | | | | | | | | | | |
|--|--------|---|---|---|---|---|---|-------------------------------|-------------------------------|---------------------------------|---------------------------------|---------------|
| | | 160 | 250 | 400 | 630 | 800 | 1000 | 1250 | 1600 | 2000 | 2500 | 3200 |
| E | 25 | A160E – TF A160E – FF B160E – FF | A250E – TM | P400E-TM | P630E – TM | | | | | | | |
| F | 36 | A160F – TF P160F – FF P160F – TM P160F – BE P160F – BEG P160F – SE | A250F – TM P250F – TM P250F – BE P250F – BEG P250F – SE | P400F – TM P400F – BE P400F – BEG P400F – SE | P630F – TM P630F – BE P630F – BEG P630F – SE | B800F – TM | | | | | | |
| N | 50 | P160N – TM P160N – BE P160N – BEG P160N – SE | P250N – TM P250N – BE P250N – BEG P250N – SE | P400N – TM P400N – BE P400N – BEG P400N – SE | P630N – TM P630N – BE P630N – BEG P630N – SE | B800N – TM B800N – BE B800N – SX B800N – SE | B1000N – BE B1000N – BEG B1000N – SX B1000N – SE | B1250N – BE B1250N – BEG | B1600N – BE B1600N – BEG | | | |
| H | 70 | P160H – TM P160H – BE P160H – BEG P160H – SE | P250H – TM P250H – BE P250H – BEG P250H – SE | P400H – TM P400H – BE P400H – BEG P400H – SE | P630H – TM P630H – BE P630H – BEG P630H – SE | B800H – TM B800H – BE B800H – BEG B800H – SX B800H – SE | B1000H – BE B1000H – BEG B1000H – SX B1000H – SE | B1250H – BE B1250H – BEG | | | | |
| HL | 85 | | | | | | | B1250HL – BE B1250HL – BEG | B1600HL – BE B1600HL – BEG | XS2000HL – BE XS2000HL – BEG | XS2500HL – BE XS2500HL – BEG | XS3200HL – BE |
| G | 100 | | | | | B800G – TM B800G – BE B800G – BEG B800G – SX B800G – SE | | | | | | |
| S | 110 | | | P400S – TM P400S – BE P400S – BEG P400S – SE | P630S – TM P630S – BE P630S – BEG P630S – SE | | | | | | | |
| P | 125 | B160P – TM | B250P – TM B250P – BE B250P – SE | B400P – BE B400P – BEG | | B800P – BE B800P – BEG B800P – SX B800P – SE | | | | | | |
| R | 200 | B160R – TM | B250R – TM | B400P – BE B400P – BEG | | B800R – BE B800R – BEG B800R – SX B800R – SE | | | | | | |
| D | Switch | A160D – NN P160D – NN | A250D – NN P250D – NN | P400D – NN | P630D – NN | B800D – NN | B1000D – NN | B1250D – NN | B1600D – NN | XS2000D – NN | XS2500D – NN | |

Product Information

Label Identification


The label on the MCCB features information to aid in product identification.



| Description | Notes | | | | | | | | | | | | | | | | | | |
|-------------------------------|---|------------|----------------|--------|-------------|--------------|-----------|------------|-------------------|--------|-------------|--------------|------------|------------|--------|--------|------|--------------|------------|
| 1 Circuit Break Identifier | Identifies the model type, ampere frame, and I_{cu} rating. | | | | | | | | | | | | | | | | | | |
| 2 Trip unit type | <p>The trip unit type is indicated by the colour of the label.</p> <div style="display: flex; align-items: flex-start;"> <div style="margin-right: 20px;">  </div> <div> <p>White label – Thermal-magnetic type trip unit</p> <table border="1"> <tr> <td>Trip Units</td> <td>FF, TF, FM, TM</td> </tr> <tr> <td>Models</td> <td>A, P, B, ZS</td> </tr> <tr> <td>Ampere Frame</td> <td>125 – 800</td> </tr> </table> </div> </div> <div style="display: flex; align-items: flex-start; margin-top: 10px;"> <div style="margin-right: 20px;">  </div> <div> <p>Grey label – electronic or non-auto type trip unit. To distinguish between the two, electronic trip units will have the “I_{cu}” letter and non-auto will use the letter “D”, Switch.</p> <table border="1"> <tr> <td>Trip Units</td> <td>BE, BEG, BEGN, NN</td> </tr> <tr> <td>Models</td> <td>A, P, B, XS</td> </tr> <tr> <td>Ampere Frame</td> <td>160 – 3200</td> </tr> </table> </div> </div> <div style="display: flex; align-items: flex-start; margin-top: 10px;"> <div style="margin-right: 20px;">  </div> <div> <p>Blue Label – SMART electronic type trip unit</p> <table border="1"> <tr> <td>Trip Units</td> <td>SX, SE</td> </tr> <tr> <td>Models</td> <td>P, B</td> </tr> <tr> <td>Ampere Frame</td> <td>160 – 1000</td> </tr> </table> </div> </div> | Trip Units | FF, TF, FM, TM | Models | A, P, B, ZS | Ampere Frame | 125 – 800 | Trip Units | BE, BEG, BEGN, NN | Models | A, P, B, XS | Ampere Frame | 160 – 3200 | Trip Units | SX, SE | Models | P, B | Ampere Frame | 160 – 1000 |
| Trip Units | FF, TF, FM, TM | | | | | | | | | | | | | | | | | | |
| Models | A, P, B, ZS | | | | | | | | | | | | | | | | | | |
| Ampere Frame | 125 – 800 | | | | | | | | | | | | | | | | | | |
| Trip Units | BE, BEG, BEGN, NN | | | | | | | | | | | | | | | | | | |
| Models | A, P, B, XS | | | | | | | | | | | | | | | | | | |
| Ampere Frame | 160 – 3200 | | | | | | | | | | | | | | | | | | |
| Trip Units | SX, SE | | | | | | | | | | | | | | | | | | |
| Models | P, B | | | | | | | | | | | | | | | | | | |
| Ampere Frame | 160 – 1000 | | | | | | | | | | | | | | | | | | |
| 3 Certifications | Identifies the additional localised certifications of the product, in addition to the international product standard, IEC 60947-2 / AS/NZS IEC 60947-2. For additional certifications please contact NHP. | | | | | | | | | | | | | | | | | | |


Product Information

P160_BE and P250_BE Information

| Frame / Model | Attribute | Unit | Condition | P160F | P160N | P160H | P250F | P250N | P250H |
|---|-----------------|---------------------------------------|--------------|-------|-------|-------|-------|-------|-------|
| Number of Poles | | | | 3, 4 | 3, 4 | 3, 4 | 3, 4 | 3, 4 | 3, 4 |
| Nominal current ratings | I_{CT} | (A) | @ 50°C | 40 A | 40 A | 40 A | 40 A | 40 A | 40 A |
| Trip unit ratings | | | | 100 A | 100 A | 100 A | 100 A | 100 A | 100 A |
| | | | | 160 A | 160 A | 160 A | 160 A | 160 A | 160 A |
| | | | | — | — | — | 250 A | 250 A | 250 A |
| Electrical characteristics | | | | | | | | | |
| Rated maximum operational voltage | U_e | (V) | AC 50/60 Hz | 690 | 690 | 690 | 690 | 690 | 690 |
| | | (V) | DC | — | — | — | — | — | — |
| Rated insulation voltage | U_i | (V) | | 800 | 800 | 800 | 800 | 800 | 800 |
| Rated impulse withstand voltage | U_{imp} | (kV) | | 8 | 8 | 8 | 8 | 8 | 8 |
| Selectivity category | | | | A | A | A | A | A | A |
| Rated short time withstand current | I_{cw} | (kA) | 0.4 sec | — | — | — | — | — | — |
| Ultimate breaking capacity (IEC, JIS, AS/NZS) | I_{cu} | (kA) | 690 Vac | 6 | 6 | 6 | 6 | 6 | 6 |
| | | | 400 /415 Vac | 36 | 50 | 70 | 36 | 50 | 70 |
| | | | 240 Vac | 50 | 85 | 85 | 50 | 85 | 85 |
| Service breaking capacity (IEC, JIS, AS/NZS) | I_{cs} | (kA) | 690 Vac | 6 | 6 | 6 | 6 | 6 | 6 |
| | | | 400 /415 Vac | 36 | 50 | 50 | 36 | 50 | 50 |
| | | | 220 /240 Vac | 50 | 85 | 85 | 50 | 85 | 85 |
| Protection - Over Current Release types | | | | | | | | | |
| BE 6 dial Adjustable LSI | Std | Standard | | Std | Std | Std | Std | Std | Std |
| BE-G 7 dial Adjustable LSIG (Ground Fault) | Opt | Optional | | Std | Std | Std | Std | Std | Std |
| BE Instantaneous only setting (ICB) ¹⁾ | — | Not Available | | Std | Std | Std | Std | Std | Std |
| LT Adjustable 40% to 100% in 1% increments | M Req | Module Required | | Std | Std | Std | Std | Std | Std |
| Instantaneous setting independently adjustable | | | | Std | Std | Std | Std | Std | Std |
| Installation (Std / Opt / —) | | | | | | | | | |
| Front connection (FC) | Std Opt — | Standard Optional Not Available | | Std | Std | Std | Std | Std | Std |
| Extension bar (FB) | | | Opt | Opt | Opt | Opt | Opt | Opt | |
| Cable tunnel clamp (FW) | | | Opt | Opt | Opt | Opt | Opt | Opt | |
| Rear Connection (RC) | | | Opt | Opt | Opt | Opt | Opt | Opt | |
| DIN rail adaptor | | | Opt | Opt | Opt | Opt | Opt | Opt | |
| Withdrawable mechanism | | | Opt | Opt | Opt | Opt | Opt | Opt | |
| Plug-in | | | Opt | Opt | Opt | Opt | Opt | Opt | |
| Reverse supply connection possible to 440V | | | | Yes | Yes | Yes | Yes | Yes | Yes |
| Dimensions | | | | | | | | | |
|  | H | (mm) | | 130 | 130 | 130 | 165 | 165 | 165 |
| | W | (mm) | 1 pole | — | — | — | — | — | — |
| | | | 2 pole | — | — | — | — | — | |
| | | | 3 pole | 90 | 90 | 90 | 105 | 105 | 105 |
| | | | 4 pole | 120 | 120 | 120 | 140 | 140 | 140 |
| | D | (mm) | | 68 | 68 | 68 | 68 | 68 | 68 |
| T | (mm) | | 95.5 | 95.5 | 95.5 | 95.5 | 95.5 | 95.5 | |
| Weight | W | (kg) | 3 pole | 1.0 | 1.0 | 1.0 | 1.5 | 1.5 | 1.5 |
| 4 pole | | | 1.3 | 1.3 | 1.3 | 2 | 2 | 2 | |
| Operation options (Std / Opt / —) | | | | | | | | | |
| Toggle operation | Std | Standard | | Std | Std | Std | Std | Std | Std |
| Extension handle TP-HS/HP or Direct mount T2HB | Opt | Optional | | Opt | Opt | Opt | Opt | Opt | Opt |
| Motor operation TP-MC | — | Not Available | | Opt | Opt | Opt | Opt | Opt | Opt |
| Endurance | | | | | | | | | |
| Endurance | Electrical | Cycles | 415 Vac | 30000 | 30000 | 30000 | 10000 | 10000 | 10000 |
| | Mechanical | Cycles | | 50000 | 50000 | 50000 | 30000 | 30000 | 30000 |


Product Information

P400_BE Information

| Frame / Model | Attribute | Unit | Condition | P400F | P400N | P400H | P400S |
|---|-----------------|---------------------------------------|-------------------|-------|-------|-------|-------|
| Number of Poles | | | | 3, 4 | 3, 4 | 3, 4 | 3, 4 |
| Nominal current ratings | I_{CT} | (A) | @ 50°C | 250 A | 250 A | 250 A | 250 A |
| Trip unit ratings | | | | 400 A | 400 A | 400 A | 400 A |
| Electrical characteristics | | | | | | | |
| Rated maximum operational voltage | U_e | (V) | AC 50/60 Hz DC | 690 | 690 | 690 | 690 |
| | | (V) | | — | — | — | — |
| Rated insulation voltage | U_i | (V) | | 800 | 800 | 800 | 800 |
| Rated impulse withstand voltage | U_{imp} | (kV) | | 8 | 8 | 8 | 8 |
| Selectivity category | | | | B | B | B | B |
| Rated short time withstand current | I_{cw} | (kA) | 0.4 sec | 5 | 5 | 5 | 5 |
| Ultimate breaking capacity (IEC, JIS, AS/NZS) | I_{cu} | (kA) | 690 Vac | 7 | 12 | 12 | 12 |
| | | | 400 /415 Vac | 36 | 50 | 70 | 110 |
| | | | 240 Vac | 50 | 85 | 100 | 125 |
| Service breaking capacity (IEC, JIS, AS/NZS) | I_{cs} | (kA) | 690 Vac | 7 | 12 | 12 | 12 |
| | | | 400 /415 Vac | 36 | 50 | 70 | 110 |
| | | | 220 /240 Vac | 50 | 85 | 100 | 125 |
| Protection - Over Current Release types | | | | | | | |
| BE 6 dial Adjustable LSI | Std | Standard | | Std | Std | Std | Std |
| BE-G 7 dial Adjustable LSIG (Ground Fault) | Opt | Optional | | Std | Std | Std | Std |
| BE Instantaneous only setting (ICB) ¹⁾ | — | Not Available | | Std | Std | Std | Std |
| LT Adjustable 40% to 100% in 1% increments | M Req | Module Required | | Std | Std | Std | Std |
| Instantaneous setting independently adjustable | | | | Std | Std | Std | Std |
| Installation (Std / Opt / —) | | | | | | | |
| Front connection (FC) | Std Opt — | Standard Optional Not Available | | Std | Std | Std | Std |
| Extension bar (FB) | | | | Std | Std | Std | Std |
| Cable tunnel clamp (FW) | | | | Opt | Opt | Opt | Opt |
| Rear connection (RC) | | | | Opt | Opt | Opt | Opt |
| DIN rail adaptor | | | | — | — | — | — |
| Withdrawable mechanism | | | | Opt | Opt | Opt | Opt |
| Plug-in | | | | Opt | Opt | Opt | Opt |
| Reverse supply connection possible to 440V | | | | Yes | Yes | Yes | Yes |
| Dimensions | | | | | | | |
|  | H | (mm) | | 260 | 260 | 260 | 260 |
| | W | (mm) | 1 pole | — | — | — | — |
| | | | 2 pole | — | — | — | — |
| | | | 3 pole | 140 | 140 | 140 | 140 |
| | | | 4 pole | 185 | 185 | 185 | 185 |
| | D | (mm) | | 103 | 103 | 103 | 103 |
| T | (mm) | | 145 | 145 | 145 | 145 | |
| Weight | | | | | | | |
| | W | (kg) | 3 pole | 4.3 | 4.3 | 4.3 | 4.3 |
| | | | 4 pole | 5.7 | 5.7 | 5.7 | 5.7 |
| Operation options (Std / Opt / —) | | | | | | | |
| Toggle operation | Std | Standard | | Std | Std | Std | Std |
| Extension handle TP-HS/HP or Direct mount T2HB | Opt | Optional | | Opt | Opt | Opt | Opt |
| Motor operation TP-MC | — | Not Available | | Opt | Opt | Opt | Opt |
| Endurance | Electrical | Cycles | 415 Vac | 6000 | 6000 | 6000 | 6000 |
| | Mechanical | Cycles | | 15000 | 15000 | 15000 | 15000 |

Product Information

P630_BE Information

| Frame / Model | Attribute | Unit | Condition | P630F | P630N | P630H | P630S |
|---|------------|-----------------|-------------------|-------|-------|-------|-------|
| Number of Poles | | | | 3, 4 | 3, 4 | 3, 4 | 3, 4 |
| Nominal current ratings | I_{CT} | (A) | 50°C | 630A | 630A | 630A | 630A |
| Trip unit ratings | | | | | | | |
| Electrical characteristics | | | | | | | |
| Rated maximum operational voltage | U_e | (V) | AC 50/60 Hz DC | 690 | 690 | 690 | 690 |
| | | (V) | | — | — | — | — |
| Rated insulation voltage | U_i | (V) | | 800 | 800 | 800 | 800 |
| Rated impulse withstand voltage | U_{imp} | (kV) | | 8 | 8 | 8 | 8 |
| Selectivity category | | | | A | A | A | A |
| Rated short time withstand current | I_{cw} | (kA) | 0.4 sec | — | — | — | — |
| Ultimate breaking capacity | | | | | | | |
| (IEC, JIS, AS/NZS) | | | | | | | |
| | I_{cu} | (kA) | 690 Vac | 7 | 12 | 12 | 12 |
| | | | 400 /415 Vac | 36 | 50 | 70 | 110 |
| | | | 240 Vac | 50 | 85 | 100 | 125 |
| Service breaking capacity | | | | | | | |
| (IEC, JIS, AS/NZS) | | | | | | | |
| | I_{cs} | (kA) | 690 Vac | 7 | 12 | 12 | 12 |
| | | | 400 /415 Vac | 36 | 50 | 70 | 110 |
| | | | 220 /240 Vac | 50 | 85 | 100 | 125 |
| Protection - Over Current Release types | | | | | | | |
| BE 6 dial Adjustable LSI | Std | Standard | | Std | Std | Std | Std |
| BE-G 7 dial Adjustable LSIG (Ground Fault) | Opt | Optional | | Std | Std | Std | Std |
| BE Instantaneous only setting (ICB) ¹⁾ | — | Not Available | | Std | Std | Std | Std |
| LT Adjustable 40% to 100% in 1% increments | M Req | Module Required | | Std | Std | Std | Std |
| Instantaneous setting independently adjustable | | | | Std | Std | Std | Std |
| Installation (Std / Opt / —) | | | | | | | |
| Front connection (FC) | | | | Std | Std | Std | Std |
| Extension bar (FB) | | | | Std | Std | Std | Std |
| Cable tunnel clamp (FW) | | | | Opt | Opt | Opt | Opt |
| Rear connection (RC) | | | | Opt | Opt | Opt | Opt |
| DIN rail adaptor | | | | — | — | — | — |
| Withdrawable mechanism | | | | Opt | Opt | Opt | Opt |
| Plug-in | | | | Opt | Opt | Opt | Opt |
| Reverse supply connection possible to 440V | | | | Yes | Yes | Yes | Yes |
| Dimensions | | | | | | | |
|  | H | (mm) | | 260 | 260 | 260 | 260 |
| | W | (mm) | 1 pole | — | — | — | — |
| | | | 2 pole | — | — | — | — |
| | | | 3 pole | 140 | 140 | 140 | 140 |
| | | | 4 pole | 185 | 185 | 185 | 185 |
| | D | (mm) | | 103 | 103 | 103 | 103 |
| T | (mm) | | 145 | 145 | 145 | 145 | |
| Weight | | | | | | | |
| | W | (kg) | 3 pole | 5.0 | 5.0 | 5.0 | 5.0 |
| | | | 4 pole | 6.6 | 6.6 | 6.6 | 6.6 |
| Operation options (Std / Opt / —) | | | | | | | |
| Toggle operation | Std | Standard | | | | | |
| Extension handle TP-HS/HP or Direct mount T2HB | Opt | Optional | | Std | Std | Std | Std |
| Motor operation TP-MC | — | Not Available | | Opt | Opt | Opt | Opt |
| | | | | Opt | Opt | Opt | Opt |
| Endurance | | | | | | | |
| | Electrical | Cycles | 415 Vac | 4000 | 4000 | 4000 | 4000 |
| | Mechanical | Cycles | | 15000 | 15000 | 15000 | 15000 |

Internal Accessories

Internal accessories include Auxiliary and Alarm contacts, Shunt Trip and Undervoltage Trip (UVT) modules, which may be installed under the front cover of the MCCB in various combinations to provide additional functionality and connection with external control circuits.

Auxiliary & Alarm Switches

Auxiliary Contact

An auxiliary contact can be installed to indicate whether an MCCB is Open (both OFF and Tripped positions) or Closed (ON). Auxiliary contacts come in either general purpose or micro-switch type, with some combinations pre-wired or with terminals. Each contact type is provided as a single change-over switching arrangement (1x C/O).

Alarm Contact

An alarm contact can be installed to indicate whether an MCCB is in the Tripped or Not Tripped position (ON, OFF). Alarm contacts come in either general purpose or micro-switch type, with some combinations pre-wired or with terminals. Each contact type is provided as a single change-over switching arrangement (1x C/O).



| Part Number | Description | Contact Type | Connection Type |
|---------------|-----------------------|-----------------|-----------------|
| T2AX00LML3SWA | Auxiliary | General purpose | Pre-wired |
| T2AX00LML3STA | Auxiliary | General purpose | Terminal |
| T2AX00LML3RWA | Auxiliary | Micro-switch | Pre-wired |
| T2AL00LML3SWA | Alarm; left side only | General purpose | Pre-wired |
| T2AL00LML3STA | Alarm; left side only | General purpose | Terminal |
| T2AL00LML3RWA | Alarm; left side only | Micro-switch | Pre-wired |

| General purpose contact | | | | | | |
|-------------------------|----------------|----------------|-----------|----------------|----------------|--------------|
| AC (V) | | | DC (V) | | | Minimum Load |
| Volts (V) | Amperes (A) | | Volts (V) | Amperes (A) | | |
| | Resistive Load | Inductive Load | | Resistive Load | Inductive Load | |
| 480 | — | — | 250 | — | — | |
| 250 | 3 | 2 | 125 | 0.4 | 0.05 | |
| 125 | 3 | 2 | 30 | 3 | 2 | |

| Micro-switch contact | | |
|----------------------|-------------|--------------|
| DC (V) | | Minimum Load |
| Volts (V) | Amperes (A) | |
| 30 | 0.1 | 1 mA @ 5 Vdc |

Internal Accessories

Shunt Trip

A shunt (normally de-energized) can be installed to trip the MCCB by applying voltage to the shunt coil.



| Part Number | Rated voltage | | Connection Type |
|--------------|---------------|--------|----------------------|
| | AC (V) | DC (V) | |
| T2SH00LA10T | 110 | — | Terminal |
| T2SH00LA20T | 230...240 | — | Terminal |
| T2SH00LA40T | 400...415 | — | Terminal |
| T2SH00LD01T | — | 12 | Terminal |
| T2SH00LD02T | — | 24 | Terminal |
| T2SH00LD04T | — | 48 | Terminal |
| T2SH00LD10T | — | 110 | Terminal |
| T2SH00LD20T | — | 230 | Terminal |
| T2SH00LA10WA | 110 | — | Pre-wired cage clamp |
| T2SH00LA20WA | 230...240 | — | Pre-wired cage clamp |
| T2SH00LA40WA | 400...415 | — | Pre-wired cage clamp |
| T2SH00LD01WA | — | 12 | Pre-wired cage clamp |
| T2SH00LD02WA | — | 24 | Pre-wired cage clamp |
| T2SH00LD04WA | — | 48 | Pre-wired cage clamp |
| T2SH00LD10WA | — | 110 | Pre-wired cage clamp |
| T2SH00LD20WA | — | 230 | Pre-wired cage clamp |

| Rated voltage | AC (V) | | | DC (V) | | | | |
|-------------------------|-----------|-----------|-----------|--------|-------|------|-----------|-----------|
| | 100...120 | 200...240 | 380...450 | 12 | 24 | 48 | 100...120 | 200...240 |
| Excitation current (mA) | 16.0 | 16.0 | 6.2 | 160.0 | 124.0 | 32.0 | 14.0 | 12.0 |

Under Voltage Trips

A UVT (normally energized) can be installed to trip the MCCB removing voltage from the UVT coil.





| Part Number | Rated voltage | | Compatible MCCB | | Connection Type | Notes |
|---------------|---------------|--------|-----------------|------------|----------------------|------------------|
| | AC (V) | DC (V) | 3P | 4P | | |
| T2UV00LA10NT | 110 | — | All | P160 / 250 | Terminal | Instantaneous |
| T2UV00LA20NT | 230...240 | — | All | P160 / 250 | Terminal | Instantaneous |
| T2UV00LA40NT | 400...440 | — | All | P160 / 250 | Terminal | Instantaneous |
| T2UV00LD02NT | — | 24 | All | P160 / 250 | Terminal | Instantaneous |
| T2UV00LD10NT | — | 110 | All | P160 / 250 | Terminal | Instantaneous |
| T2UV00LD20NT | — | 230 | All | P160 / 250 | Terminal | Instantaneous |
| T2UV00LA10DS | 110 | — | All | P160 / 250 | Terminal | Time Delay 500ms |
| T2UV00LA24DS | 230...240 | — | All | P160 / 250 | Terminal | Time Delay 500ms |
| T2UV00LA45DS | 440...450 | — | All | P160 / 250 | Terminal | Time Delay 500ms |
| T2UV00LD02DS | — | 24 | All | P160 / 250 | Terminal | Time Delay 500ms |
| T2UV00LD10DS | — | 110 | All | P160 / 250 | Terminal | Time Delay 500ms |
| T2UV00LD24DS | — | 230 | All | P160 / 250 | Terminal | Time Delay 500ms |
| T2UV00LA10DL | 110 | — | — | P400 / 630 | Terminal | Time Delay 500ms |
| T2UV00LA24DL | 230...240 | — | — | P400 / 630 | Terminal | Time Delay 500ms |
| T2UV00LA40DL | 380...415 | — | — | P400 / 630 | Terminal | Time Delay 500ms |
| T2UV00LA45DL | 440...450 | — | — | P400 / 630 | Terminal | Time Delay 500ms |
| T2UV00LD02DL | — | 24 | — | P400 / 630 | Terminal | Time Delay 500ms |
| T2UV00LD10DL | — | 110 | — | P400 / 630 | Terminal | Time Delay 500ms |
| T2UV00LD24DL | — | 230 | — | P400 / 630 | Terminal | Time Delay 500ms |
| T2UV00LA10NWA | 110 | — | All | P160 / 250 | Pre-wired cage clamp | Instantaneous |
| T2UV00LA20NWA | 230...240 | — | All | P160 / 250 | Pre-wired cage clamp | Instantaneous |
| T2UV00LA40NWA | 440...450 | — | All | P160 / 250 | Pre-wired cage clamp | Instantaneous |
| T2UV00LD02NWA | — | 24 | All | P160 / 250 | Pre-wired cage clamp | Instantaneous |
| T2UV00LD10NWA | — | 110 | All | P160 / 250 | Pre-wired cage clamp | Instantaneous |
| T2UV00LD20NWA | — | 230 | All | P160 / 250 | Pre-wired cage clamp | Instantaneous |

| Rated Voltage | AC (V) | | | DC (V) | | |
|-------------------------|-----------|-----------|-----------|--------|-----------|-----------|
| | 100...120 | 200...240 | 380...450 | 24 | 100...120 | 200...240 |
| Excitation current (mA) | 1.3 | 1.1 | 2.0 | 22.0 | 9.0 | 3.7 |

Plugs & Ports

The P_BE circuit breaker is equipped with specific connectors for connecting interfacing devices and accessories.

| Port | | Description |
|------|---|---|
| PTA |  | Used to connect the PTA output contact to send the pre-trip alarm over a local signalling circuit. Located on the outside left-hand side of the MCCB. |
| MIP |  | Maintenance Interface Port – for temporary connection to OCR testing, servicing, and maintenance tools. Located to the right of the embedded display front cover. |



Notice: Port images are representative only. Locations differ slightly for the various ampere frame sizes

Installation

Precautions




WARNING: To prevent electrical shock and damage to equipment, disconnect and isolate power source upstream of the MCCB before installing or servicing the MCCB including its connected accessories.



Notice: To ensure correct performance, and integrity of equipment, the installation instructions and recommendations provided herein shall be respected. Refer to the respective user manual and installation instructions provided with the MCCB and associated accessories.


Mounting Angles

TemBreak *PRO* MCCBs may be mounted at any angle without affecting performance.



Direction of Power Supply

Power supply may be fed in either direction with respect to the MCCB without affecting performance.



Installation

Clearances




WARNING: Exposed conductors including terminals at attached busbars must be insulated to avoid possible short-circuit or earth faults due any foreign matter coming into contact with the conductors.

Phase to Phase and Earth

Interruption of large currents during fault or normal switching operation produces ionised gases and arcing materials which expelled from the vents at the top of the MCCB for P160/P250, and top and bottom for P400/P630. These ionised gases are highly conductive, concentrated, and at an elevated temperature when it exits the MCCB via the arc vents. Care must be taken to avoid an arcing fault from occurring due to the presence of concentrated ionised gases creating a conductive path between exposed conductors. Incoming conductors must therefore be insulated the full length up to the terminal opening of the MCCB, ensuring bare conductors are not exposed directly to concentrated ionised gases. This also applies to the attached busbars supplied as part of the MCCB.

Interpole barriers or terminal covers may be used to achieve creepage and clearance requirements. Conductors must not impede the flow of ionised gas and allow it to clear and disperse safely. Interpole barriers are supplied as standard with Terasaki MCCBs for the line side only. 2 barriers with 3P MCCBs and 3 with 4P MCCBs. In cases where two different MCCB types are installed one above the other, the insulation distance between the two models should be as for the lower model.



Installation

Insulating Distance


When earth metal is installed within proximity of the breakers, the correct insulating distance must be maintained, (refer to Minimum Clearance). This distance is necessary to allow the exhausted arc gases to disperse. This could include the mounting plate or side panel within a switchboard.

Minimum Clearance

Below illustrates the minimum clearance that must be maintained.

| Dim. | Description |
|----------------|--|
| A | Distance from lower breaker to open charging part of terminal on upper breaker (front connection) or the distance from lower breaker to upper breaker end (rear connection and plug-in type) |
| B ₁ | Distance from breaker end to ceiling (earthed metal) |
| B ₂ | Distance from breaker end to insulator |
| C | Clearance between breakers |
| D | Distance from breaker side to side plate (earthed metal) |
| E | Length of insulation over exposed conductors. |

| MCCB Cat. No. | Distances (mm) | | | | | |
|-------------------|----------------|----------------|----------------|---|----|---|
| | A | B ₁ | B ₂ | C | D | E |
| P160F | 50 | 10 | 10 | 0 | 25 | ^ |
| P160N / H / D | 75 | 45 | 25 | 0 | 25 | ^ |
| P250F | 50 | 40 | 30 | 0 | 25 | ^ |
| P250N / H / D | 80 | 80 | 30 | 0 | 25 | ^ |
| P400F / N / H / D | 100 | 80 | 60 | 0 | 80 | ^ |
| P400S | 120 | 120 | 80 | 0 | 80 | ^ |
| P630F / N / H / D | 100 | 80 | 60 | 0 | 80 | ^ |
| P630S | 120 | 120 | 80 | 0 | 80 | ^ |



^ Insulate the exposed conductor until it overlaps the moulded case at the terminal, or the terminal cover.

Installation


Internal Accessory Mounting Locations

P160, P250 and P400/630 frame sizes have different internal mounting locations for auxiliary contacts, alarm contacts, shunts and, UVTs.

Left-side and right-side mounting locations are independent and accept unique combinations. For example, shunts and UVTs may only be mounted on the right side, whereas auxiliary and alarm contacts may be mounted on either left or right side.

Refer to the following illustrations for each frame size listing the various possible internal accessories combinations.


P160 internal accessories combination




Installation

Internal Accessory Mounting Locations

P250 internal accessories combination




Legend




Installation

Internal Accessory Mounting Locations

P400/630 internal accessories combination



Legend



Notice: Only 2 internal accessories can be mounted on the right-hand side of a P400 and P630 MCCB. Under no circumstances can 3 or more be installed.

Examples:

- 2 AUX
- 1 Alarm and 1 AUX
- 1 Shunt and 1 AUX
- 1 UVT and 1 AUX

Installation

Alarm, Shunt & UVT Installation

The alarm, shunt and UVT have a trip bar that needs to interact with the MCCBs trip mechanism. As such they must be installed in a specific way. Refer to the supplied Installation Instructions for the respective accessories for further detail.

Standard Alarm & Auxiliary installation

| Action | Note |
|--|------|
| 1 Switch the Smart MCCB to the Tripped Position. | |
| 2 Open the front cover of the MCCB. | |
| 3 Locate the alarm's trip bar into the MCCB trip mechanism slot. | |
| 4 The alarm will need to be rolled into place, follow the images to the right. | |
| 5 Run the wires out the left-hand side of the MCCB, through the allocated groves. | |

Installation

Alarm, Shunt & UVT Installation

Shunt & UVT installation


| Action | Note |
|--|------|
| 1 Switch the Smart MCCB to the Tripped Position. | |
| 2 Open the front cover of the MCCB. | |
| 3 Locate the shunt or UVT's trip bar into the MCCB trip mechanism slot. | |
| 4 The shunt or UVT will need to be rolled into place, follow the images to the right. | |
| 5 Run the wires out the right-hand side of the MCCB, through the allocated groves. | |

Protection Settings

Trip Curve

The TemBreak PRO P_BE electronic trip unit protects against overcurrent and short circuit faults for many types of electrical distribution systems. The P_BE OCR has protective characteristics according to the requirements of the standard AS/NZS IEC 60947-2.


All protection functions are based on the effective value (RMS) of power, to reduce the effects of current harmonics. The wide range of protection curves adjustments assist in being able to achieve Selectivity combinations of upstream and downstream protection.



List of Protection Functions

| Abbreviation | Description | Protection against | Symbol | Definition |
|--------------|-----------------------------------|----------------------------|----------------|--|
| L | Long-time delay (LTD) protection | Low level current overload | I_r | Threshold long time protection |
| | | | t_r | Long Time Delay |
| S | Short-time delay (STD) protection | Low level short-circuit | I_{sd} | Threshold short time protection |
| | | | t_{sd} | Short Time Delay |
| | | | I^t ON / OFF | I^t curve on Short delay protection activated or not |
| I | Instantaneous (INST) protection | Larger short-circuit | I_i | Instantaneous protection threshold |
| G | Ground/Earth protection | Ground / Earth fault | I_g | Earth Protection Threshold |
| | | | t_g | Delay protection Earth |
| | | | I^t ON / OFF | I^t curve on Earth protection or not activated |


Time-current curve



Protection Settings

Long Time Delay (LTD) protection

The Long Time Delay protection protects against current overloads or surges in power distribution or motor control applications. Long Time Delay protection is an inverse-time protection which includes a thermal image function.



| | Long Time Delay Settings | Description |
|---|--------------------------|---|
| L | I_r | Long Time Delay protection threshold (current rating) |
| | t_r | Long Time Delay (time delay) |

Equation

The t_r time delay defines the trip time of the long-time delay protection at a $6 \times I_r$. The time to trip at any given current is calculated using the below formula, where k is a constant specific to I_r and t_r settings.

The derivation of the constant k is given by the below formula, where t_r is equal to the t_r setting, I_r equal to the I_r setting and where I equals $6 \times I_r$.

| | |
|-----------------------------------|--|
| P Model Long Time Equation | $k = \frac{-t_r}{\log_e \left(1 - \left(\frac{1.125 \times I_r}{I} \right)^2 \right)}$ |
|-----------------------------------|--|

Example

P250H3250SE with the below LTD settings

$$I_{r1} = 250A$$

$$I_{r2} = 1.0$$

$$t_r = 5s$$

k constant is calculated as below for this example.

$$k = \frac{-t_r}{\log_e \left(1 - \left(\frac{1.125 \times I_r}{I} \right)^2 \right)} = \frac{-5}{\log_e \left(1 - \left(\frac{1.125 \times I_r}{6 \times I_r} \right)^2 \right)} = \frac{-5}{\log_e \left(1 - \left(\frac{1.125}{6} \right)^2 \right)} = 139.71$$

$$I_r = I_{r1} \times I_{r2} = 250A \times 1.0 = 250A$$

Now the LTD curve for a P250_BE with the above LTD settings can be plotted using the below

$$t_r = - \left(139.71 \times \log_e \left(1 - \left(\frac{1.125 \times 250}{I} \right)^2 \right) \right), \text{ where } t_r \text{ is the time delay for a given value of } I$$

Protection Settings

Long Time Delay (LTD) protection

Adjusting I_r (Current)


The LTD protection trip range is: $1.05 \dots 1.20 \times I_r$ according to standard AS/NZS IEC 60947.2.

The trip threshold tolerance I_r for the long-time delay protection is +5% to +20%.

The I_r trip threshold is adjusted using two I_r dials on the front of the MCCB:

I_{r1} – maximum scale adjustment

I_{r2} – fine adjustment of the maximum scale in increments of 1%



The I_r threshold is firstly set using the I_{r1} dial to set the maximum current range, then, if necessary, from the I_{r2} dial further adjustments in fine increments of 1% can be made from OFF to $0.92 \times I_{r1}$ dial. Refer to the [Commissioning – LTD Adjustments \(\$I_r, t_r\$ \)](#) section for further information on using the I_{r1} and I_{r2} adjustment dials.



WARNING: Setting I_{r2} to OFF will disable both LTD and STD protection modes; therefore, the MCCB will provide instantaneous protection only.

| Rating (I_n) | Dial position | | | | | | | | | |
|------------------|------------------|------------------|------------------|------------------|------------------|------------------|------------------|------------------|------------------|------------------|
| | 1 | 2 | 3 | 4 | 5 | 6 | 7 | 8 | 9 | 10 |
| 40A | I_{r1} max 16 | I_{r1} max 18 | I_{r1} max 20 | I_{r1} max 22 | I_{r1} max 25 | I_{r1} max 28 | I_{r1} max 32 | I_{r1} max 34 | I_{r1} max 37 | I_{r1} max 40 |
| | 14.72...16 | 16.56...18 | 18.4...20 | 20.24...22 | 23...25 | 25.76...28 | 29.44...32 | 31.28...34 | 34.04-37 | 36.8-40 |
| 100A | I_{r1} max 40 | I_{r1} max 45 | I_{r1} max 50 | I_{r1} max 57 | I_{r1} max 63 | I_{r1} max 72 | I_{r1} max 80 | I_{r1} max 87 | I_{r1} max 93 | I_{r1} max 100 |
| | 36.8...40 | 41.4...45 | 46...50 | 52.44...57 | 57.96...63 | 66.24...72 | 73.6...80 | 80.04...87 | 85.56-93 | 92-100 |
| 160A | I_{r1} max 63 | I_{r1} max 70 | I_{r1} max 80 | I_{r1} max 90 | I_{r1} max 100 | I_{r1} max 110 | I_{r1} max 125 | I_{r1} max 135 | I_{r1} max 150 | I_{r1} max 160 |
| | 58...63 | 64.4...70 | 73.6...80 | 82.8...90 | 92...100 | 101.2...110 | 115...125 | 124.2...135 | 138-150 | 147.2-160 |
| 250A | I_{r1} max 100 | I_{r1} max 110 | I_{r1} max 125 | I_{r1} max 140 | I_{r1} max 160 | I_{r1} max 180 | I_{r1} max 200 | I_{r1} max 225 | I_{r1} max 250 | |
| | 92...100 | 101.2...110 | 115...125 | 128.8...140 | 147.2...160 | 165.6...180 | 184...200 | 207...225 | 230-250 | |
| 400A | I_{r1} max 160 | I_{r1} max 180 | I_{r1} max 200 | I_{r1} max 225 | I_{r1} max 250 | I_{r1} max 300 | I_{r1} max 350 | I_{r1} max 370 | I_{r1} max 400 | |
| | 147.2...160 | 165.6...180 | 184...200 | 207...225 | 230...250 | 276...300 | 322...350 | 340.4...370 | 368-400 | |
| 630A | I_{r1} max 250 | I_{r1} max 300 | I_{r1} max 350 | I_{r1} max 370 | I_{r1} max 400 | I_{r1} max 500 | I_{r1} max 600 | I_{r1} max 630 | | |
| | 230...250 | 276...300 | 322...350 | 340.4...370 | 368...400 | 460...500 | 552...600 | 579.6...630 | | |


| |
|------------------------------------|
| I_{r1} max scale setting (A) |
| I_{r2} fine adjustment range (A) |

Protection Settings

Long Time Delay (LTD) protection

Adjusting t_r (Time Delay)

The t_r time delay defines the trip time of the long-time delay protection for a current of $6 \times I_r$ and adjustable via the t_r dial.



| t_r Adjustment Range (seconds) | | | | | | | | | |
|----------------------------------|-----|-----|---|-----|---|----|----|----|----|
| 0.5 | 1.5 | 2.5 | 5 | 7.5 | 9 | 10 | 12 | 14 | 16 |



Notice: For the following MCCBs the setting of I_r and t_r can limit the setting of I_{sd} for STD protection.

P160_BE $I_n = 160A$, P250_BE $I_n = 250A$

If: $I_r > 0.9 \times I_n$ and $t_r = 16s$ I_{sd} is limited to $9 \times I_r$, even if the dial is set to $10x$



Notice: The trip time tolerance for LTD protection is $-20\% + 20ms$ to $0\% + 30ms$.

Example:

For $t_r = 5s$ and $I = 6 \times I_r$, the trip time for long time delay protection will be between 4.02 s and 5.03 s.

Protection Settings

Long Time Delay (LTD) protection

Thermal memory / Hot-Cold start mode

TemBreak *PRO* electronic OCRs have a thermal imaging function, which models the active heating and cooling of electrical conductors as current passes through them. The thermal imaging function calculates a thermal value (θ) for the conductors, which trips the MCCB when its thermal threshold (θ_{trip}) is reached. This allows the MCCB to simulate the true thermal state of the conductors more accurately, and better protect against overload conditions between successive operating cycles.

Thermal imaging cannot be disabled in the OCR, however, the P_BE model can be supplied with either a hot or cold start mode, which determines whether the calculated thermal value θ is retained if the current drops below the LTD pick-up current threshold (between 1.05...1.20 x I_r).

The standard P_BE OCR is supplied with Cold start mode only. If Hot start mode is required, a made-to-order P_BE can be supplied. Contact NHP for details on the Hot start mode option.

Alternatively, the P_SE model can be configured with either a hot or cold start mode using the embedded display, or TPCM or TPED accessories.


Hot start mode

In Hot start mode, the thermal imaging continues to calculate the thermal value (θ_H), even if the current is below the LTD pick-up threshold. As long as the OCR is powered (self-supply or external backup power), the thermal imaging will continue to function. If power is removed from the OCR, thermal imaging will continue to operate for at least 20 minutes or until the calculated thermal value θ_H reaches 0.

Cold start mode

In Cold start mode, the thermal value (θ_C) is only calculated from when the current reaches and exceeds the LTD pick-up current threshold. If the current drops below the LTD pick-up current threshold, then the thermal value θ_C resets to 0.


The below figure illustrates the OCR with thermal imaging in both hot and cold start modes. Where the current (I) drops below the LTD pick-up current threshold (region in grey between 105...120% of I_r), the Hot mode thermal value θ_H continues to be calculated, whereas the Cold mode thermal value θ_C resets to 0 each time. In either start mode, the MCCB trips when the respective thermal value threshold θ_{trip} is reached. The differences between start modes is made most apparent by the different tripping times after successive operations, where hot mode θ_H reaches the tripping threshold θ_{trip} earlier, providing added safety and optimum protection of the conductors.



Protection Settings

Short Time Delay Protection (STD)

The short time protection is designed to protect against low level short circuits.




| | Short Time Delay Settings | Description |
|----------|---------------------------|---------------------------------------|
| S | $I_{sd} (x I_r)$ | Short Time Delay protection threshold |
| | $t_{sd} (ms)$ | Short Time Delay |
| | $I^2t (ON / OFF)$ | Inverse I^2t time |

Protection Settings

Adjusting I_{sd} (Current)

The I_{sd} trip threshold tolerance for STD protection is $\pm 10\%$.
Adjustments to I_{sd} can be made via the I_{sd} adjustment dial, which is represented as a multiple of I_r .



For example: I_r is set to 120A, I_{sd} dial in position 5 sets I_{sd} to $5 \times 120A = 600A (\pm 10\%)$.

| I _{sd} Threshold Adjustment | | | | | | | | | | |
|--------------------------------------|-----|---|---|---|---|---|---|---|----|-----|
| Dial Position | 1 | 2 | 3 | 4 | 5 | 6 | 7 | 8 | 9 | 10 |
| I _{sd} | 1.5 | 2 | 3 | 4 | 5 | 6 | 7 | 8 | 10 | OFF |



Notice: For the following MCCBs the setting of I_r and t_r can limit the setting of I_{sd} for STD protection.

P160_BE $I_n = 160A$, P250_BE $I_n = 250A$

If: $I_r > 0.9 \times I_n$ and $t_r = 16s$ I_{sd} is limited to $9 \times I_r$, even if the dial is set to 10x



Notice: In the case where STD protection is disabled ($I_{sd} = OFF$), thermal self-protection parameters I_{tsp} and t_{tsp} are automatically enabled on the following trip units:

P160_BE $I_n = 160A$, P250_BE $I_n = 250A$

In this case, a supplementary $I^2t = K$ curve is added to the end of LTD tripping curve, starting from I_{tsp} , where constant $K = \text{Max}(I_i)^2 \times t_{tsp}$.

$\text{Max}(I_i)$ is the maximum I_i settable on the trip unit and is not adjustable.

Refer to [Thermal Self-Protection](#) section.

Protection Settings

Short Time Delay Protection (STD)


Adjusting t_{sd} (Time Delay)

The t_{sd} time delay can be adjusted from the t_{sd} dial, where the tripping delay is given in milliseconds (ms).

An I^2t function for STD can be enabled by setting the t_{sd} dial to a value on the right side, or I^2t disabled by setting a value on the left side.

For example: The figure below displays t_{sd} set to 100ms with I^2t for STD as enabled.

See [I²t function for STD](#) section for more information.



| t_{sd} Time Delay Adjustment Settings (ms) | | | | |
|--|-----|-----|-----|-----|
| 50 | 100 | 200 | 300 | 400 |

The trip time tolerance for short time delay protection is as follows:


- For $t_{sd} = 50$ ms: ± 30 ms
- For $t_{sd} \geq 100$ ms: -20 ms / $+50$ ms

Protection Settings

Short Time Delay Protection (STD)


I²t function for STD

When enabled, the I²t function for STD may be used to improve selectivity with downstream devices by overlaying a supplementary I²t = K curve within the STD tripping section, starting from the I_{sd} threshold setting up to the I_i threshold setting.



The below graphic illustrates the difference between I²t enabled and disabled with a I²t curve based on I_r = 630A for reference.

| Settings | Full curve without I ² t enabled | Full curve with I ² t enabled | I ² t ONLY base on I _r =630A |
|------------------|---|--|--|
| I _r | 630A | 630A | 630A |
| t _r | 5s | 5s | 5s |
| I _{sd} | 5 | 5 | 1.5 |
| t _{sd} | 50ms | 50ms | 50ms |
| I _i | 9 | 9 | 11 |
| I ² t | Disabled | Enabled | Enabled |




Protection Settings

Short Time Delay Protection (STD)

I²t function for STD

The I²t curve is based on the setting of I_r. The below time current graph illustrates the effect of the I²t curves calculated for different I_r settings.

| Settings | I ² t ONLY base on I _r =630A | Full curve with I ² t enabled |
|------------------|---|---|
| I _r | 630A | 350A |
| t _r | 5s | 5s |
| I _{sd} | 1.5 | 3 |
| t _{sd} | 50ms | 50ms |
| I _i | 11 | 9 |
| I ² t | Enabled | Enabled |



Protection Settings


Short Time Delay Protection (STD)

I²t function for STD

Thermal Self Protection

Thermal self-protection is enabled automatically where STD is disabled. This is to ensure that the continuation of the LTD curve does not intersect with the Critical Area of the MCCB, which could create overheating stresses in the MCCB and cause irreparable damage and/or undesirable operation or failure of the trip-unit.

To achieve this, a supplementary I²t = K curve is added to the end of LTD tripping curve, starting from I_{tsp}, where constant K = Max(I_i)² × t_{tsp}. Max(I_i) is the maximum I_i settable on the trip unit and is not adjustable.



For the following MCCBs I_{tsp} and t_{tsp} values are specifications.

| MCCB | I _{tsp} × I _r | t _{tsp} (seconds) |
|-------------------------------|-----------------------------------|----------------------------|
| P160_BE I _n = 160A | 8 | 2 |
| P250_BE I _n = 250A | 8 | 2 |


Notice: Thermal self-protection is applied to all phases where LTD protection is enabled. In the case of 4P MCCBs, Thermal self-protection is also applied to the neutral pole (irrespective of the N Coefficient parameter) provided that Neutral Protection (NP) is enabled. Refer to [Neutral Protection](#) section.

Notice: LTD thermal image value θ is only affected during a trip event where it is temporarily forced to a value over 100%.

Protection Settings

Instantaneous Protection (INST)

Instantaneous protection is designed to protect against high current short circuits. This protection is independent of time and is set as a multiple of the rated current I_n .




| | Instantaneous Protection Settings | Description |
|---|-----------------------------------|------------------------------------|
| I | $I_i (x I_n)$ | Instantaneous protection threshold |

Adjusting I_i (Current)

The I_i trip threshold tolerance for instantaneous protection is $\pm 15\%$.
The instantaneous protection has no adjustable time delay.
The non-trip time is 10 ms with a maximum cut-out time is 50 ms.

The I_i trip threshold can be adjusted from the I_i dial, which is represented as a multiple of I_n .




| Rated I_n | I_i Adjustment Settings ($x I_n$) | | | | | | | | | |
|-------------------------|---------------------------------------|---|---|---|---|---|----|----|----|----|
| | Dial Position | | | | | | | | | |
| | 1 | 2 | 3 | 4 | 5 | 6 | 7 | 8 | 9 | 10 |
| 40 | 3 | 4 | 5 | 6 | 7 | 8 | 10 | 12 | 15 | 15 |
| 100 | 3 | 4 | 5 | 6 | 7 | 8 | 9 | 10 | 11 | 11 |
| 160 | 3 | 4 | 5 | 6 | 7 | 8 | 10 | 11 | 12 | 12 |
| 250 (P250 Ampere Frame) | 3 | 4 | 5 | 6 | 7 | 8 | 10 | 11 | 12 | 12 |
| 250 (P400 Ampere Frame) | 3 | 4 | 5 | 6 | 7 | 8 | 9 | 10 | 11 | 11 |
| 400 | 3 | 4 | 5 | 7 | 7 | 8 | 9 | 10 | 11 | 11 |
| 630 | 3 | 4 | 5 | 7 | 7 | 8 | 9 | 10 | 11 | 11 |

Protection Settings

Ground/Earth Fault Protection (GF)

Ground Fault (GF) protection is protection against high strength insulation / earth faults. An LSIG P_BE OCR is required for both 3P and 4P MCCBs to permit GF protection. P_BE OCRs with LIS only do not have GF protection.




| | Ground Fault Protection Settings | Description |
|----------|----------------------------------|-----------------------------------|
| G | $I_g = 0.4 \times I_n$ | Ground fault protection threshold |
| | $t_g = 200 \text{ ms}$ | Ground fault delay |

GF pickup current I_g is fixed at $I_g = 0.4 \times I_n$ and is not adjustable. The I_g trip threshold tolerance for ground protection is $\pm 10\%$.

GF time delay t_g is also fixed at $t_g = 200\text{ms}$ and is not adjustable. The trip time tolerance for ground protection is $-20 \text{ ms} / +50 \text{ ms}$

GF protection can be turned ON or OFF using the GF dial on 3P MCCBs by setting the dial to the ON or OFF position respectively. For 4P MCCBs, the N (%) dial is also used for turning GF protection ON or OFF by setting the dial to any position on the right for ON, or any position on the left for OFF. See [Neutral Protection \(NP\)](#) section for more information on the N (%) dial.



Notice: Enabling GF for 3 pole MCCBs on a 4-wire system may result in nuisance tripping in the case of imbalanced loads. It is recommended in this case that GF should be disabled.

Protection Settings


Neutral Protection (NP)

Neutral protection is available with 4P P_BE MCCBs with LSIG OCR. It is particularly useful when the cross-section of the neutral conductor is reduced in relation to the phase conductors.


Neutral protection is based off the standard LTD and STD protection parameter of the main phases. The I_r and I_{sd} parameters for the Neutral pole are adjusted according to the set Neutral Coefficient percentage. For example, If the Neutral conductor is sized at 50% of the main phases, and the N Coefficient Adjustment parameter is set to 50%, then I_r and I_{sd} of the Neutral pole will be 50% of I_r and I_{sd} of main phase poles.

The time delays for the Neutral pole remain identical to the t_r and t_{sd} time delay adjustment values for the main phases and cannot be independently changed.

INST protection of the Neutral pole is not affected by the N Coefficient adjustment setting and is identical to the I_i trip threshold of the main phases.



The Neutral Coefficient percentage can be adjusted from the N (%) dial. GF protection is also turned ON or OFF by setting the dial to any position on the right for ON, or any position on the left for OFF. See [Ground/Earth Fault Protection \(GF\)](#) section for more information on the N (%) dial.



| N Coefficient Adjustment Settings (%) | Parameters Impacted |
|---------------------------------------|---|
| 50 – 100 – OFF | The coefficient is applied to the adjustment value of the phase I_r and I_{sd} thresholds |





Notice: If the I^2t function for STD is enabled, I^2t will also be included in the Neutral Protection curve as calculated from the Neutral pole I_r parameter.

Alarms & Indication

The P_BE OCR provides alarming for various types of events based on system status and live monitoring of parameters. There are three types of alarms to indicate OCR health and trip status:

- **System alarm:** Correspond to predefined events internal to the OCR.
- **Trip alarm:** Provide warning about trip events.
- **Pre-Trip alarm (PTA):** Provides a warning about the imminent trip risk due to a current overload. It is associated with the PTA output contact.

Indicators in the form of LEDs on the front display various operational status changes and alarms for P_BE OCR.





| Alarm/Status type | Indication | LED Status | Description |
|-----------------------|---|-----------------|-----------------------------------|
| OCR Temperature Alarm |  | RED Solid | Internal OCR temperature > 105°C |
| LTD Pick-up Alarm |  | OFF | Current < 105% x I _r |
| | | RED Flashing | Current ≥ 105% x I _r |
| | | RED Solid | Current ≥ 112.5% x I _r |
| PTA (Pre-Trip Alarm) |  | OFF | Current < 80% x I _r |
| | | ORANGE Flashing | Current ≥ 80% x I _r |
| | | ORANGE Solid | PTA output activated |
| OCR Status |  | GREEN Solid | OCR operating normally |
| | | ORANGE Flashing | Internal OCR fault detected |

System Alarms

System alarms are produced as a result of either an internal OCR error, or overtemperature of the OCR itself.

OCR Temperature: The P_BE OCR constantly monitors its internal temperature. In the event that the temperature exceeds 105°C, the *OCR temperature alarm* is activated and the OCR Temperature Alarm LED illuminates solid red. The alarm features a lower hysteresis threshold, which keeps the alarm active until the internal temperature of the OCR drops below 100°C.




Internal OCR error: The P_BE OCR constantly monitors its protection function. In the event of an operating fault concerning the electronics of the OCR, the *Internal trip unit error* alarm is activated and the OCR Status LED flashes orange.

| Alarm/Status type | LED Status | Description |
|-----------------------|--|----------------------------------|
| OCR Temperature Alarm | OFF  | Internal OCR temperature < 105°C |
| | RED Solid  | Internal OCR temperature > 105°C |
| OCR Status | GREEN Solid  | OCR operating normally |
| | ORANGE Flashing  | Internal OCR fault detected |

Alarms & Indication

Trip Alarm

The trip alarm on the P_OCR indicates the status of the LTD protection, which if flashing indicates that an LTD trip is imminent.

| Alarm/Status type | LED Status | Description |
|-------------------|---|-----------------------------------|
| LTD Pick-up Alarm | OFF  | Current < 105% x I _r |
| | RED Flashing  | Current ≥ 105% x I _r |
| | RED Solid  | Current ≥ 112.5% x I _r |

Alarms & Indication

PTA (Pre-Trip Alarm)

The Pre-Trip Alarm permits monitoring and early warning of overload conditions prior to an actual LTD trip. The PTA setting is defined by two parameters which define the Pre-trip warning and Pre-trip Alarm zones and thus the behaviour of the PTA contact and status LED:

- PTA current threshold I_p : Threshold expressed as a percentage of I_r and is fixed at $80\% \times I_r$.
- PTA time delay t_p : Expressed as a percentage of t_r and is fixed at $50\% \times t_r$.

The I_p current threshold defines the lowest current that could be considered to be within the Pre-trip warning and Pre-trip alarm zones. The t_p time delay threshold defines the shortest time in which the Pre-trip alarm will activate. The time delay for PTA follows the LTD protection curve and varies with current as shown in the figure below. Lower currents in the Pre-trip zones will activate the alarm with a longer delay than higher currents.

The behaviour of the various pre-trip zones are illustrated in the figure and table below.

If the load current is less than the I_p current threshold, then this is considered the normal load zone, and the PTA LED and contact are unaffected and remain OFF and OPEN, respectively.


As the load current increases to at or above I_p , the Pre-trip warning zone is entered, and is indicated by the PTA LED illuminating FLASHING orange. Whilst in the pre-trip warning zone, the load current is monitored and characterised with thermal imaging by the OCR.

If the current remains above I_p for an extended period of time, the Pre-trip Alarm zone is entered, and is indicated by the PTA LED illuminating SOLID orange, and the PTA contact activating CLOSED. The time required for the Pre-trip Alarm to activate is dependent on the current value and the t_p parameter set, as this follows the LTD protection curve.



Notice: The use of the PTA contact requires the connection of the OAC/PTA cable to the PTA port located on the external left-hand side of the P_BE MCCB. Refer to the [OAC and PTA cable](#) section below for details

| Pre-trip zone | Current I vs. I_p | PTA LED status | PTA Contact status |
|----------------------|-------------------------------|----------------|--------------------|
| Normal load | $I < I_p (0.8 \times I_r)$ | OFF | OPEN |
| Pre-trip Warning | $I \geq I_p (0.8 \times I_r)$ | FLASHING | OPEN |
| Pre-trip Alarm | $I \geq I_p (0.8 \times I_r)$ | SOLID | CLOSED |



OAC and PTA cable

The P_BE MCCB provides an on-board digital output for use with the Pre-Trip Alarm (PTA), which is used with the corresponding cable:

| Connector | Accessories Reference | Length | Number of Wires | Switching rating |
|------------|---------------------------|--------|-----------------|-------------------------|
| OAC or PTA | TPPHQTT130H – OAC and PTA | 1.20m | 2 | Max. 100mA at 24V ac/dc |



OCR Power Supply

Power to the P_BE OCR is self-powered whilst sufficient current is flowing through the MCCB, which provides a minimum power supply to operate and provide alarm and configured protection functions

Minimum conditions for energizing the trip unit without an external power supply:

- Circuit breaker closed
- Minimum current through the circuit breaker; below is a table per rating

| Trip unit rating | 1 Pole fed | 2 Poles fed | 3 Poles fed |
|------------------|------------|-------------|-------------|
| 40A | — | > 14A | > 10A |
| 100A | > 25A | > 15A | > 15A |
| 160A | > 32A | > 16A | > 16A |
| 250A | > 50A | > 25A | > 25A |
| 400A | > 80A | > 40A | > 40A |
| 630A | > 126A | > 63A | > 63A |



Notice: 40A trip unit with 1 Pole feed, will still provide INST protection for $I > 2x I_n$ (>80A).

Commissioning



WARNING: Before applying power to the MCCB for the first time, an initial inspection must be performed.



WARNING: Risk of nuisance tripping. Only qualified personnel are to set the protection levels. Failure to respect these instructions may cause death, serious injuries or equipment damage.

LTD Adjustments (I_r , t_r)

The LTD protection is configured by the I_r and t_r adjustment rotary dials, which is performed as follows. Refer to [Protection Settings – Long Time Delay Protection \(LTD\)](#) section for further detail on setting I_r and t_r .

| Action | Note / Illustration |
|---|---------------------|
| <p>1 Turn the MCCB to the OFF Position</p> <p>Open the transparent flap to access the max I_r adjustment dials</p> | |
| <p>2 Using a PH1, PH2 or PZ2 size screwdriver, rotate the I_{r1} adjustment dial to the maximum scale value of I_r in Amperes.</p> | |
| <p>3 If required, turn the I_{r2} fine adjustment dial to the required percentage of the maximum scale I_{r1} as configured in the previous step.</p> <p>NOTE: To turn off LTD protection, set I_{r2} to the OFF position. This will also disable STD protection and the OCR will be set as INST protection only.</p> <p>See INST Protection Only Setting.</p> | |
| <p>4 Set the time delay by rotating the t_r dial to the required value in seconds.</p> | |

Commissioning

STD Adjustments (I_{sd} , t_{sd})

The STD protection is configured by the I_r and t_{sd} adjustment rotary dials, which is performed as follows. Refer to [Protection Settings – Short Time Delay Protection \(STD\)](#) section for further detail on setting I_{sd} and t_{sd}

| Action | Note / Illustration |
|---|---------------------|
| <p>1</p> <p>Turn the MCCB to the OFF Position</p> <p>Open the transparent flap to access I_{sd} adjustment dials</p> | |
| <p>2</p> <p>Using a PH1, PH2 or PZ2 size screwdriver, rotate the I_{sd} adjustment dial to the required multiple of I_r.</p> <p>NOTE: To turn off STD protection, set I_{r2} to the OFF position, this will</p> | |
| <p>3</p> <p>Set the time delay by rotating the t_{sd} dial to the required value in seconds.</p> <p>NOTE: There are two sides to the t_{sd} dial to enable or disable the I_{r2} function for STD: Right side to enable, and left side to disable.</p> | |

Commissioning

INST Protection Adjustments (I_i)

The INST protection is configured by the I_i adjustment rotary dial, which is performed as follows. Refer to [Protection Settings – Instantaneous Protection \(INST\)](#) section for further detail on setting I_i.

| | Action | Note / Illustration |
|---|--|---------------------|
| 1 | <p>Turn the MCCB to the OFF Position</p> <p>Open the transparent flap to access I_i adjustment dials</p> | |
| 2 | <p>Using a PH1, PH2 or PZ2 size screwdriver, rotate the I_i adjustment dial to the required multiple of I_n.</p> | |

Commissioning

INST Protection Only Setting

The P_BE OCR can be configured for INST protection only by disabling LTD (and STD) protection modes as follows: Refer to [Protection Settings – Instantaneous Protection \(INST\)](#) section for further detail on setting I_i .

| | Action | Note / Illustration |
|---|---|---------------------|
| 1 | <p>Turn the MCCB to the OFF Position</p> <p>Open the transparent flap to access I_i adjustment dials</p> | |
| 2 | <p>Using a PH1, PH2 or PZ2 size screwdriver, rotate the I_i adjustment dial to the OFF position.</p> | |
| 3 | <p>Rotate the I_i adjustment dial to the required multiple of I_n.</p> | |

Commissioning

LSIG 3P – GF Protection Adjustments (I_g)

On the LSIG 3P variant P_BE MCCB, the GF protection is configured by the GF adjustment rotary dials, which is used to enable or disable GF protection, and is performed as follows. Refer to [Protection Settings – Ground/Earth Fault Protection \(GF\)](#) section for further detail on GF protection.

| | Action | Note / Illustration |
|---|---|---------------------|
| 1 | <p>Turn the MCCB to the OFF Position</p> <p>Open the transparent flap to access GF adjustment dials</p> | |
| 2 | <p>Using a PH1, PH2 or PZ2 size screwdriver, rotate the GF adjustment dial to either ON or OFF position to enable or disable GF protection, respectively.</p> | |

Commissioning

LSIG 4P – NP and GF Protection Adjustments (I_n , I_g)

On the LSIG 4P variant P_BE MCCB, both NP and GF protection modes are configured by the N (%) adjustment rotary dials, which is performed as follows. Refer to [Protection Settings – Ground/Earth Fault Protection \(GF\)](#) and [Neutral Protection \(NP\)](#) sections for further detail on NP and GF protection.

| | Action | Note / Illustration |
|---|--|---------------------|
| 1 | <p>Turn the MCCB to the OFF Position</p> <p>Open the transparent flap to access N(%) adjustment dial</p> | |
| 2 | <p>Using a PH1, PH2 or PZ2 size screwdriver, rotate the N(%) adjustment dial to the desired N Coefficient value.</p> <p>NOTE: There are two sides to the N(%) dial to enable or disable GF protection: Right side to enable, and left side to disable.</p> | |

Troubleshooting

In the event of a problem when using the TemBreak *PRO* system, this section provides advice on how to resolve issues.


| | Problem description | Possible cause | Remedial advice |
|---|--|---|---|
| 1 | Ready LED OFF | Insufficient or no power to the OCR | Verify power supply requirements. Refer to OCR Power Supply section. MCCB must be closed and load drawing sufficient current through main poles. Verify the current through the MCCB poles meets the minimum requirements. |
| | | Incorrect or faulty wiring | Verify integrity of wiring and connections. Verify and correct any: <ul style="list-style-type: none"> - Loose connections to line and load terminals - Incorrect terminals / conductors / connector pins |
| 2 | Ready LED flashing orange | Incorrect settings | Verify adjustment dials are in correct defined positions |
| | | OCR is faulty | Replace MCCB |
| 3 | OCR over temperature alarm (Internal OCR temperature > 105°C) | Excessive ambient temperature. | Verify ambient temperature surrounding the MCCB do not exceed the maximum rated ambient temperature range (-25°C...+70°C) |
| | | Loose terminal screw or conductor connecting screw. | Verify and correct any loose connections to load and line terminals. Refer to torque and connection requirements in TemBreak <i>PRO</i> P_BE Installation Instructions supplied with MCCB |
| | | Increased contact resistance, loose internal connection or contact failure. | Replace MCCB |
| | | High proportion of high frequency distortion in load current. | Decrease distortion content of load circuit |
| 4 | Abnormal voltage on load side | Excessive wear of contacts | Replace MCCB. |
| | | Foreign matter interfering with contacts or contact surfaces | |
| 5 | Failure in ON position | Reset operation not conducted after tripping operation. | Perform reset operation. |
| 6 | Failure in RESET position | UVT not energised | Apply voltage to UVT |
| | | Circuit breaker service life ended due to large number of switching cycles using SHT or UVT | Replace MCCB |
| | | Fault of tripping mechanism | |
| 7 | Nuisance tripping while rated current not reached | Vibration and/or shock | Dampen vibration of MCCB and review installation requirements |
| | | High proportion of high frequency distortion in load current. | Decrease distortion content of load circuit |
| | | Electromagnetic induced interference (from nearby conductors or external radio sources) | Review nearby sources of conducted and radiated emissions (e.g. radio sources, high-speed switching devices including variable frequency drives) |
| | | Excessive surge | Isolate and mitigate surge source (e.g. surge protection devices) |
| | | Erroneous connection of control circuit for SHT or UVT | Verify control wiring and supply to SHT and UVT |

Troubleshooting

| | Problem description | Possible cause | Remedial advice |
|---|---|---|--|
| 8 | Nuisance tripping due to starting current | Excessive inrush starting current due to load type | Review INST and STD protection settings for load type where applicable |
| | | Switching operation of star-delta motor starter, incorrect wiring | Verify and correct any issues with star-delta starter wiring with respect to the motor windings and phase sequence. Refer to motor and/or starter manufacturer |
| | | Short-circuit in motor (e.g. windings, starter circuit) | Verify and correct any issues with motor wiring. Inspect and verify motor winding insulation. Refer to motor manufacturer |
| | | Erroneous connection of control circuit for SHT or UVT | Verify control wiring and supply to SHT and UVT |
| 9 | No trip at pickup current | Failure in selectivity/coordination with upstream circuit breaker or fuse | Review selectivity/coordination study and protection parameters of each device |
| | | Incorrect protection settings | Review enabled protection settings ensuring correct pickup current and time-delay for load type. (e.g. LTD, STD, INST pickup currents and time delays) |


Annex A – Dimensions

P160 Dimensions




Annex A – Dimensions

P250 Dimensions




Annex A – Dimensions

P400 Dimensions



Annex A – Dimensions


P630 Dimensions



Annex B – Trip Curves




Notice: The below trip curve is representative only. The P_BE OCR features fully configurable protection settings with fine adjustment to pick-up current and time delay for the various respective trip curves, which can change depending on the application. To aide in selectivity studies, a trip curve based on the actual settings used can be generated using the software package TemCurve. Contact NHP for details on TemCurve and Selectivity.



Annex C – I²t Let-Through Curves


P160_BE

Let-through energy characteristics U = 220/380VAC ~ 240/415VAC




Annex C – I²t Let-Through Curves

P250_BE




Annex C – I²t Let-Through Curves

P400_BE




Annex C – I²t Let-Through Curves

P630_BE




Annex D – Peak Let Through Curves

P160_BE




Annex D – Peak Let Through Curves

P250_BE




Annex D – Peak Let Through Curves

P400_BE



Annex D – Peak Let Through Curves

P630_BE



Annex E – Watts Loss

Impedance Watts Loss

| Frame | Rating In (A) | Impedance per pole (mΩ) | Watts Loss per pole Based from Impedance (W) | Pole numbers | Watts Loss per product Based from Impedance (W) |
|-----------|---------------|-------------------------|--|--------------|---|
| P160_BE/G | 40 | 0.35 | 0.6 | 3/4P | 1.8 |
| | 100 | 0.35 | 3.5 | | 10.5 |
| | 160 | 0.35 | 9.0 | | 27 |
| P250_BE/G | 40 | 0.24 | 0.4 | 3/4P | 1.2 |
| | 100 | 0.24 | 2.4 | | 7.2 |
| | 160 | 0.24 | 6.1 | | 18.3 |
| | 250 | 0.24 | 15.0 | | 45 |
| P400_BE/G | 250 | 0.18 | 11.1 | 3/4P | 33.3 |
| | 400 | 0.18 | 28.4 | | 85.2 |
| P630_BE/G | 630 | 0.13 | 52.0 | 3/4P | 156 |

Resistance Watts Loss

| Frame | Rating In (A) | Resistance per pole (mΩ) | Watts Loss per pole Based from Resistance (W) | Pole numbers | Watts Loss per product Based from Resistance (W) |
|-----------|---------------|--------------------------|---|--------------|--|
| P160_BE/G | 40 | 0.144 | 0.23 | 3/4P | 0.69 |
| | 100 | 0.144 | 1.44 | | 4.32 |
| | 160 | 0.144 | 3.69 | | 11.07 |
| P250_BE/G | 40 | 0.127 | 0.2032 | 3/4P | 0.6096 |
| | 100 | 0.127 | 1.27 | | 3.81 |
| | 160 | 0.127 | 3.2512 | | 9.7536 |
| | 250 | 0.127 | 7.9375 | | 23.8125 |
| P400_BE/G | 250 | 0.128 | 8.0 | 3/4P | 24 |
| | 400 | 0.128 | 20.5 | | 61.5 |
| P630_BE/G | 630 | 0.064 | 25.4 | 3/4P | 76.2 |

Annex F – Rated Temperature Tables

Maximum setting of the I_r at the nominated current at the specified ambient.

Values in bold are the maximum value for I_r , different combinations of I_{r1} and I_{r2} can be set if the combined settings are not greater than the I_r value advised.

P160 Electronic

| MCCB Type | Connection Type | OCR Type | OCR Rating | Setting | Rated Current (A) | | | | | | | |
|-----------|--|-----------|------------|--------------|-------------------|------------|------------|------------|------------|------------|--------------|--------------|
| | | | | | 40°C | 45°C | 50°C | 55°C | 60°C | 65°C | 70°C | |
| P160 | Front Conn. Rear Conn. Plug-in Conn. | BE BEG | 40A | I_r (A) | 40 | 40 | 40 | 40 | 40 | 40 | 40 | 40 |
| | | | | I_{r1} (A) | 40 | 40 | 40 | 40 | 40 | 40 | 40 | |
| | | | | I_{r2} | 1 | 1 | 1 | 1 | 1 | 1 | 1 | |
| | Front Conn. Rear Conn. Plug-in Conn. | BE BEG | 100A | I_r (A) | 100 | 100 | 100 | 100 | 100 | 100 | 100 | 100 |
| | | | | I_{r1} (A) | 100 | 100 | 100 | 100 | 100 | 100 | 100 | |
| | | | | I_{r2} | 1 | 1 | 1 | 1 | 1 | 1 | 1 | |
| | Front Conn. Rear Conn. | BE BEG | 160A | I_r (A) | 160 | 160 | 160 | 160 | 160 | 160 | 156.8 | 145.5 |
| | | | | I_{r1} (A) | 160 | 160 | 160 | 160 | 160 | 160 | 160 | |
| | | | | I_{r2} | 1 | 1 | 1 | 1 | 1 | 0.98 | 0.97 | |
| | Plug-in Conn. | BE BEG | 160A | I_r (A) | 125 | 125 | 125 | 125 | 125 | 125 | 120 | 110 |
| | | | | I_{r1} (A) | 125 | 125 | 125 | 125 | 125 | 125 | 110 | |
| | | | | I_{r2} | 1 | 1 | 1 | 1 | 1 | 0.96 | 1 | |

P250 Electronic

| MCCB Type | Connection Type | OCR Type | OCR Rating | Setting | Rated Current (A) | | | | | | | |
|-----------|--|-----------|------------|--------------|-------------------|------------|------------|--------------|--------------|---------------|---------------|---------------|
| | | | | | 40°C | 45°C | 50°C | 55°C | 60°C | 65°C | 70°C | |
| P250 | Front Conn. Rear Conn. Plug-in Conn. | BE BEG | 40A | I_r (A) | 40 | 40 | 40 | 40 | 40 | 40 | 40 | 40 |
| | | | | I_{r1} (A) | 40 | 40 | 40 | 40 | 40 | 40 | 40 | |
| | | | | I_{r2} | 1 | 1 | 1 | 1 | 1 | 1 | 1 | |
| | Front Conn. Rear Conn. Plug-in Conn. | BE BEG | 100A | I_r (A) | 100 | 100 | 100 | 100 | 100 | 100 | 100 | 100 |
| | | | | I_{r1} (A) | 100 | 100 | 100 | 100 | 100 | 100 | 100 | |
| | | | | I_{r2} | 1 | 1 | 1 | 1 | 1 | 1 | 1 | |
| | Front Conn. Rear Conn. | BE BEG | 160A | I_r (A) | 160 | 160 | 160 | 160 | 160 | 160 | 160 | 155.2 |
| | | | | I_{r1} (A) | 160 | 160 | 160 | 160 | 160 | 160 | 160 | |
| | | | | I_{r2} | 1 | 1 | 1 | 1 | 1 | 1 | 0.97 | |
| | Plug-in Conn. | BE BEG | 160A | I_r (A) | 160 | 160 | 160 | 160 | 160 | 160 | 160 | 148.5 |
| | | | | I_{r1} (A) | 160 | 160 | 160 | 160 | 160 | 160 | 150 | |
| | | | | I_{r2} | 1 | 1 | 1 | 1 | 1 | 1 | 0.99 | |
| | Front Conn. Rear Conn. | BE BEG | 250A | I_r (A) | 250 | 250 | 250 | 250 | 242.5 | 225 | 209.25 | 209.25 |
| | | | | I_{r1} (A) | 250 | 250 | 250 | 250 | 250 | 225 | 225 | |
| | | | | I_{r2} | 1 | 1 | 1 | 1 | 0.97 | 1 | 0.93 | |
| | Plug-in Conn. | BE BEG | 250A | I_r (A) | 250 | 250 | 250 | 242.5 | 225 | 213.75 | 198 | 198 |
| | | | | I_{r1} (A) | 250 | 250 | 250 | 250 | 225 | 225 | 200 | |
| | | | | I_{r2} | 1 | 1 | 1 | 0.97 | 1.0 | 0.95 | 0.99 | |

Annex F – Rated Temperature Tables

Maximum setting of the I_r at the nominated current at the specified ambient.

Values in bold are the maximum value for I_r , different combinations of I_{r1} and I_{r2} can be set if the combined settings are not greater than the I_r value advised.

P400 Electronic

| MCCB Type | Connection Type | OCR Type | OCR Rating | Setting | Rated Current (A) | | | | | | |
|-----------|--|-----------|--------------|--------------|-------------------|------|------|------|-------|------|------|
| | | | | | 40°C | 45°C | 50°C | 55°C | 60°C | 65°C | 70°C |
| P400 | Front Conn. Rear Conn. Plug-in Conn. | BE BEG | 250A | I_r (A) | 250 | 250 | 250 | 250 | 250 | 250 | 250 |
| | | | | I_{r1} (A) | 250 | 250 | 250 | 250 | 250 | 250 | |
| | | | | I_{r2} | 1 | 1 | 1 | 1 | 1 | 1 | |
| | BE BEG | 400A | I_r (A) | 400 | 400 | 400 | 400 | 400 | 358.9 | 300 | |
| | | | I_{r1} (A) | 400 | 400 | 400 | 400 | 400 | 370 | 300 | |
| | | | I_{r2} | 1 | 1 | 1 | 1 | 1 | 0.97 | 1 | |

P630 Electronic

| MCCB Type | Connection Type | OCR Type | OCR Rating | Setting | Rated Current (A) | | | | | | | | |
|-----------|---------------------------|-----------|------------|--------------|-------------------|------|------|------|------|------|------|------|------|
| | | | | | 30°C | 35°C | 40°C | 45°C | 50°C | 55°C | 60°C | 65°C | 70°C |
| P630 | Front Conn. Rear Conn. | BE BEG | 630A | I_r (A) | 630 | 630 | 630 | 630 | 630 | 611 | 558 | 500 | 400 |
| | | | | I_{r1} (A) | 630 | 630 | 630 | 630 | 630 | 630 | 600 | 500 | 400 |
| | | | | I_{r2} | 1 | 1 | 1 | 1 | 1 | 0.97 | 0.93 | 1 | 1 |
| | Plug-in Conn. | BE BEG | 630A | I_r (A) | 570 | 570 | 570 | 570 | 500 | 500 | 400 | 400 | 372 |
| | | | | I_{r1} (A) | 600 | 600 | 600 | 600 | 500 | 500 | 400 | 400 | 400 |
| | | | | I_{r2} | 0.95 | 0.95 | 0.95 | 0.95 | 1 | 1 | 1 | 1 | 0.93 |

Example setting

MCCB – P400H3400BE

Temperature – 65°C

| MCCB Type | Connection Type | OCR Type | OCR Rating | Setting | Rated Current (A) | | | | | | |
|-----------|--|-----------|--------------|--------------|-------------------|------|------|------|-------|------|------|
| | | | | | 40°C | 45°C | 50°C | 55°C | 60°C | 65°C | 70°C |
| P400 | Front Conn. Rear Conn. Plug-in Conn. | BE BEG | 250A | I_r (A) | 250 | 250 | 250 | 250 | 250 | 250 | 250 |
| | | | | I_{r1} (A) | 250 | 250 | 250 | 250 | 250 | 250 | |
| | | | | I_{r2} | 1 | 1 | 1 | 1 | 1 | 1 | |
| | BE BEG | 400A | I_r (A) | 400 | 400 | 400 | 400 | 400 | 358.9 | 300 | |
| | | | I_{r1} (A) | 400 | 400 | 400 | 400 | 400 | 370 | 300 | |
| | | | I_{r2} | 1 | 1 | 1 | 1 | 1 | 0.97 | 1 | |

I_{r1} dial set to 370A

I_{r2} dial set to 0.97

Therefore, the maximum at 65°C is $I_r = 370A \times 0.97 = 358.9A$

Other combinations of I_{r1} and I_{r2} in this case can be set as long as they don't exceed 358.9A.

Example: $I_r = I_{r1} \times I_{r2} = 350A \times 1.0 = 350A$



P_BE-UM-001-EN

Version

1.8.0

Published

10th February 2022

NHP Electrical Engineering Products



AU 1300 NHP NHP
NZ 0800 NHP NHP



nhp.com.au
nhp-nz.com